

§ 135.177

that thunderstorms, or other potentially hazardous weather conditions that can be detected with airborne weather radar equipment, may reasonably be expected along the route to be flown, unless the airborne weather radar equipment required by paragraph (a) of this section is in satisfactory operating condition.

(c) If the airborne weather radar equipment becomes inoperative en route, the aircraft must be operated under the instructions and procedures specified for that event in the manual required by § 135.21.

(d) This section does not apply to aircraft used solely within the State of Hawaii, within the State of Alaska, within that part of Canada west of longitude 130 degrees W, between latitude 70 degrees N, and latitude 53 degrees N, or during any training, test, or ferry flight.

(e) Without regard to any other provision of this part, an alternate electrical power supply is not required for airborne weather radar equipment.

**§ 135.177 Emergency equipment requirements for aircraft having a passenger seating configuration of more than 19 passengers.**

(a) No person may operate an aircraft having a passenger seating configuration, excluding any pilot seat, of more than 19 seats unless it is equipped with the following emergency equipment:

(1) At least one approved first-aid kit for treatment of injuries likely to occur in flight or in a minor accident that must:

(i) Be readily accessible to crewmembers.

(ii) Be stored securely and kept free from dust, moisture, and damaging temperatures.

(iii) Contain at least the following appropriately maintained contents in the specified quantities:

Contents	Quantity
Adhesive bandage compresses, 1-inch .....	16
Antiseptic swabs .....	20
Ammonia inhalants .....	10
Bandage compresses, 4-inch .....	8
Triangular bandage compresses, 40-inch .....	5
Arm splint, noninflatable .....	1
Leg splint, noninflatable .....	1
Roller bandage, 4-inch .....	4
Adhesive tape, 1-inch standard roll .....	2
Bandage scissors .....	1

14 CFR Ch. I (1–1–10 Edition)

Contents	Quantity
Protective nonpermeable gloves or equivalent .....	1 pair

(2) A crash axe carried so as to be accessible to the crew but inaccessible to passengers during normal operations.

(3) Signs that are visible to all occupants to notify them when smoking is prohibited and when safety belts must be fastened. The signs must be constructed so that they can be turned on during any movement of the aircraft on the surface, for each takeoff or landing, and at other times considered necessary by the pilot in command. “No smoking” signs shall be turned on when required by § 135.127.

(4) [Reserved]

(b) Each item of equipment must be inspected regularly under inspection periods established in the operations specifications to ensure its condition for continued serviceability and immediate readiness to perform its intended emergency purposes.

[Doc. No. 16097, 43 FR 46783, Oct. 10, 1978, as amended by Amdt. 135–25, 53 FR 12362, Apr. 13, 1988; Amdt. 135–43, 57 FR 19245, May 4, 1992; Amdt. 135–44, 57 FR 42676, Sept. 15, 1992; Amdt. 135–47, 59 FR 1781, Jan. 12, 1994; Amdt. 135–53, 59 FR 52643, Oct. 18, 1994; 59 FR 55208, Nov. 4, 1994; Amdt. 121–281, 66 FR 19045, Apr. 12, 2001]

**§ 135.178 Additional emergency equipment.**

No person may operate an airplane having a passenger seating configuration of more than 19 seats, unless it has the additional emergency equipment specified in paragraphs (a) through (1) of this section.

(a) *Means for emergency evacuation.* Each passenger-carrying landplane emergency exit (other than over-the-wing) that is more than 6 feet from the ground, with the airplane on the ground and the landing gear extended, must have an approved means to assist the occupants in descending to the ground. The assisting means for a floor-level emergency exit must meet the requirements of § 25.809(f)(1) of this chapter in effect on April 30, 1972, except that, for any airplane for which the application for the type certificate was filed after that date, it must meet