

§ 1915.135

are permanently attached to the bench or floor stand.

[47 FR 16986, Apr. 20, 1982, as amended at 61 FR 26351, May 24, 1996; 67 FR 44543, July 3, 2002]

§ 1915.135 Powder actuated fastening tools.

(a) The section shall apply to ship repairing and shipbuilding only.

(b) *General precautions.* (1) Powder actuated fastening tools shall be tested each day before loading to ensure that the safety devices are in proper working condition. Any tool found not to be in proper working order shall be immediately removed from service until repairs are made.

(2) Powder actuated fastening tools shall not be used in an explosive or flammable atmosphere.

(3) All tools shall be used with the type of shield or muzzle guard appropriate for a particular use.

(4) Fasteners shall not be driven into very hard or brittle materials such as cast iron, glazed tile, surface hardened steel, glass block, live rock, face brick or hollow tile.

(5) Fasteners shall not be driven into soft materials unless such materials are backed by a substance that will prevent the pin or fastener from passing completely through and creating a flying missile hazard on the opposite side.

(6) Unless a special guard, fixture or jig is used, fasteners shall not be driven directly into materials such as brick or concrete within 3 inches of the unsupported edge or corner, or into steel surfaces within ½ inch of the unsupported edge or corner. When fastening other material, such as 2×4 inch lumber to a concrete surface, fasteners of greater than 7/32 inch shank diameter shall not be used and fasteners shall not be driven within 2 inches of the unsupported edge or corner of the work surface.

(7) Fasteners shall not be driven through existing holes unless a positive guide is used to secure accurate alignment.

(8) No attempt shall be made to drive a fastener into a spalled area caused by an unsatisfactory fastening.

(9) Employees using powder actuated fastening tools shall be protected by personal protective equipment in ac-

29 CFR Ch. XVII (7–1–10 Edition)

cordance with the requirements of subpart I of this part.

(c) *Instruction of operators.* Before employees are permitted to use powder actuated tools, they shall have been thoroughly instructed by a competent person with respect to the requirements of paragraph (b) of this section and the safe use of such tools as follows:

(1) Before using a tool, the operator shall inspect it to determine that it is clean, that all moving parts operate freely and that the barrel is free from obstructions.

(2) When a tool develops a defect during use, the operator shall immediately cease to use it and shall notify his supervisor.

(3) Tools shall not be loaded until just prior to the intended firing time and the tool shall not be left unattended while loaded.

(4) The tool, whether loaded or empty, shall not be pointed at any person, and hands shall be kept clear of the open barrel end.

(5) In case of a misfire, the operator shall hold the tool in the operating position for at least 15 seconds and shall continue to hold the muzzle against the work surface during disassembly or opening of the tool and removal of the powder load.

(6) Neither tools nor powder charges shall be left unattended in places where they would be available to unauthorized persons.

[47 FR 16986, Apr. 20, 1982, as amended at 61 FR 26351, May 24, 1996]

§ 1915.136 Internal combustion engines, other than ship's equipment.

The provisions of this section shall apply to ship repairing, shipbuilding and shipbreaking.

(a) When internal combustion engines furnished by the employer are used in a fixed position below decks, for such purposes as driving pumps, generators, and blowers, the exhaust shall be led to the open air, clear of any ventilation intakes and openings through which it might enter the vessel.

(b) All exhaust line joints and connections shall be checked for tightness immediately upon starting the engine, and any leaks shall be corrected at once.

(c) When internal combustion engines on vehicles, such as forklifts and mobile cranes, or on portable equipment such as fans, generators, and pumps exhaust into the atmosphere below decks, the competent person shall make tests of the carbon monoxide content of the atmosphere as frequently as conditions require to ensure that dangerous concentrations do not develop. Employees shall be removed from the compartment involved when the carbon monoxide concentration exceeds 50 parts per million (0.005%). The employer shall use blowers sufficient in size and number and so arranged as to maintain the concentration below this allowable limit before work is resumed.

Subpart I—Personal Protective Equipment (PPE)

SOURCE: 61 FR 26352, May 24, 1996, unless otherwise noted.

§ 1915.151 Scope, application and definitions.

(a) *Scope and application.* This subpart applies to all work in shipyard employment regardless of geographic location.

(b) *Definitions applicable to this subpart.* *Anchorage* means a secure point of attachment for lifelines, lanyards, or deceleration devices.

Body belt means a strap with means for both securing it about the waist and attaching it to a lanyard, lifeline, or deceleration device.

Body harness means straps which may be secured about the employee in a manner that will distribute the fall arrest forces over at least the thighs, shoulders, chest and pelvis with means for attaching it to other components of a personal fall arrest system.

Connector means a device which is used to couple (connect) parts of a personal fall arrest system or parts of a positioning device system together. It may be an independent component of the system, such as a carabiner, or it may be an integral component of part of the system (such as a buckle or D-ring sewn into a body belt or body harness or a snaphook spliced or sewn to a lanyard or self-retracting lanyard).

Deceleration device means any mechanism, such as a rope grab, ripstitch

lanyard, specially woven lanyard, tearing or deforming lanyard, or automatic self-retracting lifeline/lanyard, which serves to dissipate a substantial amount of energy during a fall arrest, or otherwise limit the energy imposed on an employee during fall arrest.

Deceleration distance means the additional vertical distance a falling employee travels, excluding lifeline elongation and free fall distance, before stopping, from the point at which the deceleration device begins to operate. It is measured as the distance between the location of an employee's body belt or body harness attachment point at the moment of activation (at the onset of fall arrest forces) of the deceleration device during a fall, and the location of that attachment point after the employee comes to a full stop.

Equivalent means alternative designs, materials, or methods to protect against a hazard which the employer can demonstrate will provide an equal or greater degree of safety for employees than the method or item specified in the standard.

Free fall means the act of falling before a personal fall arrest system begins to apply force to arrest the fall.

Free fall distance means the vertical displacement of the fall arrest attachment point on the employee's body belt or body harness between onset of the fall and just before the system begins to apply force to arrest the fall. This distance excludes deceleration distance, and lifeline/lanyard elongation, but includes any deceleration device slide distance or self-retracting lifeline/lanyard extension before the device operates and fall arrest forces occur.

Lanyard means a flexible line of rope, wire rope, or strap which generally has a connector at each end for connecting the body belt or body harness to a deceleration device, lifeline, or anchorage.

Lifeline means a component consisting of a flexible line for connection to an anchorage at one end to hang vertically (vertical lifeline), or for connection to anchorages at both ends to stretch horizontally (horizontal lifeline), and which serves as a means for