- (b) Detonators are not to be stored in the same magazine with other explosive materials, except under the following circumstances:
- (1) In a type 4 magazine, detonators that will not mass detonate may be stored with electric squibs, safety fuse, shock tube, igniters, and igniter cord.
- (2) In a type 1 or type 2 magazine, detonators may be stored with delay devices and any of the items listed in paragraph (b)(1) of this section.

[T.D. ATF-487, 68 FR 3748, Jan. 24, 2003, as amended by ATF 15F, 75 FR 3163, Jan. 20, 2010]

§ 555.214 Storage within types 1, 2, 3, and 4 magazines.

- (a) Explosive materials within a magazine are not to be placed directly against interior walls and must be stored so as not to interfere with ventilation. To prevent contact of stored explosive materials with walls, a nonsparking lattice work or other nonsparking material may be used.
- (b) Containers of explosive materials are to be stored so that marks are visible. Stocks of explosive materials are to be stored so they can be easily counted and checked upon inspection.
- (c) Except with respect to fiberboard or other nonmetal containers, containers of explosive materials are not to be unpacked or repacked inside a magazine or within 50 feet of a magazine, and must not be unpacked or repacked close to other explosive materials. Containers of explosive materials must be closed while being stored.
- (d) Tools used for opening or closing containers of explosive materials are to be of nonsparking materials, except that metal slitters may be used for opening fiberboard containers. A wood wedge and a fiber, rubber, or wooden mallet are to be used for opening or closing wood containers of explosive materials. Metal tools other than nonsparking transfer conveyors are not to be stored in any magazine containing high explosives.

§555.215 Housekeeping.

Magazines are to be kept clean, dry, and free of grit, paper, empty packages and containers, and rubbish. Floors are to be regularly swept. Brooms and other utensils used in the cleaning and

maintenance of magazines must have no spark-producing metal parts, and may be kept in magazines. Floors stained by leakage from explosive materials are to be cleaned according to instructions of the explosives manufacturer. When any explosive material has deteriorated it is to be destroyed in accordance with the advice or instructions of the manufacturer. The area surrounding magazines is to be kept clear of rubbish, brush, dry grass, or trees (except live trees more than 10 feet tall), for not less than 25 feet in all directions. Volatile materials are to be kept a distance of not less than 50 feet from outdoor magazines. Living foliage which is used to stabilize the earthen covering of a magazine need not be removed.

§555.216 Repair of magazines.

Before repairing the interior of magazines, all explosive materials are to be removed and the interior cleaned. Before repairing the exterior of magazines, all explosive materials must be removed if there exists any possibility that repairs may produce sparks or flame. Explosive materials removed from magazines under repair must be (a) placed in other magazines appropriate for the storage of those explosive materials under this subpart, or (b) placed a safe distance from the magazines under repair where they are to be properly guarded and protected until the repairs have been completed.

§ 555.217 Lighting.

- (a) Battery-activated safety lights or battery-activated safety lanterns may be used in explosives storage magazines
- (b) Electric lighting used in any explosives storage magazine must meet the standards prescribed by the "National Electrical Code," (National Fire Protection Association, NFPA 70-81), for the conditions present in the magazine at any time. All electrical switches are to be located outside of the magazine and also meet the standards prescribed by the National Electrical Code.
- (c) Copies of invoices, work orders or similar documents which indicate the lighting complies with the National