

Environmental Protection Agency

§ 98.33

the applicability requirements of either § 98.2(a)(1), § 98.2(a)(2), or § 98.2(a)(3).

§ 98.32 GHGs to report.

You must report CO₂, CH₄, and N₂O mass emissions from each stationary fuel combustion unit.

§ 98.33 Calculating GHG emissions.

You must calculate CO₂ emissions according to paragraph (a) of this section, and calculate CH₄ and N₂O emissions according to paragraph (c) of this section.

(a) *CO₂ emissions from fuel combustion.* Calculate CO₂ emissions by using one of the four calculation methodologies in this paragraph (a) subject to the conditions, requirements, and restrictions set forth in paragraph (b) of this section. If you co-fire biomass fuels with fossil fuels, report CO₂ emissions from the combustion of biomass separately using the methods in paragraph (e) of this section.

(1) *Tier 1 Calculation Methodology.* Calculate the annual CO₂ mass emissions for each type of fuel by using Equation C-1 of this section.

$$CO_2 = 1 \times 10^{-3} * Fuel * HHV * EF \quad (\text{Eq. C-1})$$

Where:

CO₂ = Annual CO₂ mass emissions for the specific fuel type (metric tons).

Fuel = Mass or volume of fuel combusted per year, from company records as defined in § 98.6 (express mass in short tons for solid fuel, volume in standard cubic feet for gaseous fuel, and volume in gallons for liquid fuel).

HHV = Default high heat value of the fuel, from Table C-1 of this subpart (mmBtu per mass or mmBtu per volume, as applicable).

EF = Fuel-specific default CO₂ emission factor, from Table C-1 of this subpart (kg CO₂/mmBtu).

1×10^{-3} = Conversion factor from kilograms to metric tons.

(2) *Tier 2 Calculation Methodology.* Calculate the annual CO₂ mass emissions for each type of fuel by using either Equation C2a or C2c of this section, as appropriate.

(i) Equation C-2a of this section applies to any type of fuel listed in Table C-1 of the subpart, except for municipal solid waste (MSW). For MSW combustion, use Equation C-2c of this section.

$$CO_2 = 1 \times 10^{-3} * Fuel * HHV * EF \quad (\text{Eq. C-2a})$$

Where:

CO₂ = Annual CO₂ mass emissions for a specific fuel type (metric tons).

Fuel = Mass or volume of the fuel combusted during the year, from company records as defined in § 98.6 (express mass in short tons for solid fuel, volume in standard cubic feet for gaseous fuel, and volume in gallons for liquid fuel).

HHV = Annual average high heat value of the fuel from all valid samples for the year (mmBtu per mass or volume). The average HHV shall be calculated according to the requirements of paragraph (a)(2)(ii) of this section.

EF = Fuel-specific default CO₂ emission factor, from Table C-1 of this subpart (kg CO₂/mmBtu).

1×10^{-3} = Conversion factor from kilograms to metric tons.

(ii) The minimum number of HHV samples for determining annual average HHV is specified (e.g., monthly, quarterly, semi-annually, or by lot) in § 98.34. The method for computing the annual average HHV is a function of how frequently you perform or receive from the fuel supplier the results of fuel sampling for HHV. The method is specified in paragraph (a)(2)(ii)(A) or (a)(2)(ii)(B) of this section, as applicable.

(A) If the results of fuel sampling are received monthly or more frequently, then the annual average HHV shall be

§ 98.33

40 CFR Ch. I (7-1-10 Edition)

calculated using Equation C-2b of this section. If multiple HHV determinations are made in any month, average

the values for the month arithmetically.

$$(HHV)_{annual} = \frac{\sum_{i=1}^n (HHV)_i * (Fuel)_i}{\sum_{i=1}^n (Fuel)_i} \quad (\text{Eq. C-2b})$$

Where:

(HHV)_{annual} = Weighted annual average high heat value of the fuel (mmBtu per mass or volume).

(HHV)_i = High heat value of the fuel, for month "i" (mmBtu per mass or volume).

(Fuel)_i = Mass or volume of the fuel combusted during month "i" (express mass in short tons for solid fuel, volume in standard cubic feet for gaseous fuel, and volume in gallons for liquid fuel).

n = Number of months in the year that fuel is burned in the unit.

(B) If the results of fuel sampling are received less frequently than monthly,

then the annual average HHV shall be computed as the arithmetic average HHV for all values for the year (including valid samples and substitute data values under § 98.35).

(iii) For units that combust municipal solid waste (MSW) and that produce steam, use Equation C-2c of this section. Equation C-2c of this section may also be used for any other solid fuel listed in Table C-1 of this subpart provided that steam is generated by the unit.

$$CO_2 = 1 \times 10^{-3} \text{ Steam} * B * EF \quad (\text{Eq. C-2c})$$

Where:

CO₂ = Annual CO₂ mass emissions from MSW or solid fuel combustion (metric tons).

Steam = Total mass of steam generated by MSW or solid fuel combustion during the reporting year (lb steam).

B = Ratio of the boiler's maximum rated heat input capacity to its design rated steam output capacity (mmBtu/lb steam).

EF = Fuel-specific default CO₂ emission factor, from Table C-1 of this subpart (kg CO₂/mmBtu).

1 × 10⁻³ = Conversion factor from kilograms to metric tons.

(3) *Tier 3 Calculation Methodology.* Calculate the annual CO₂ mass emissions for each fuel by using either Equation C3, C4, or C5 of this section, as appropriate.

(i) For a solid fuel, use Equation C-3 of this section.

$$CO_2 = \frac{44}{12} * \text{Fuel} * CC * 0.91 \quad (\text{Eq. C-3})$$

Where:

CO₂ = Annual CO₂ mass emissions from the combustion of the specific solid fuel (metric tons).

Fuel = Annual mass of the solid fuel combusted, from company records as defined in § 98.6 (short tons).

CC = Annual average carbon content of the solid fuel (percent by weight, expressed as a decimal fraction, e.g., 95% = 0.95). The

Environmental Protection Agency**§ 98.33**

annual average carbon content shall be determined using the same procedures as specified for HHV in paragraph (a)(2)(ii) of this section.

44/12 = Ratio of molecular weights, CO₂ to carbon.

0.91 = Conversion factor from short tons to metric tons.

(ii) For a liquid fuel, use Equation C-4 of this section.

$$CO_2 = \frac{44}{12} * Fuel * CC * 0.001 \quad (\text{Eq. C-4})$$

Where:

CO₂ = Annual CO₂ mass emissions from the combustion of the specific liquid fuel (metric tons).

Fuel = Annual volume of the liquid fuel combusted (gallons). The volume of fuel combusted must be measured directly, using fuel flow meters calibrated according to §98.3(i). Fuel billing meters may be used for this purpose. Tank drop measurements may also be used.

CC = Annual average carbon content of the liquid fuel (kg C per gallon of fuel). The annual average carbon content shall be determined using the same procedures as specified for HHV in paragraph (a)(2)(ii) of this section.

44/12 = Ratio of molecular weights, CO₂ to carbon.

0.001 = Conversion factor from kg to metric tons.

(iii) For a gaseous fuel, use Equation C-5 of this section.

$$CO_2 = \frac{44}{12} * Fuel * CC * \frac{MW}{MVC} * 0.001 \quad (\text{Eq. C-5})$$

Where:

CO₂ = Annual CO₂ mass emissions from combustion of the specific gaseous fuel (metric tons).

Fuel = Annual volume of the gaseous fuel combusted (scf). The volume of fuel combusted must be measured directly, using fuel flow meters calibrated according to §98.3(i). Fuel billing meters may be used for this purpose.

CC = Annual average carbon content of the liquid fuel (kg C per gallon of fuel). The annual average carbon content shall be determined using the same procedures as specified for HHV in paragraph (a)(2)(ii) of this section.

MW = Annual average molecular weight of the gaseous fuel (kg/kg-mole). The annual average carbon content shall be determined using the same procedures as specified for HHV in paragraph (a)(2)(ii) of this section.

MVC = Molar volume conversion factor (849.5 scf per kg-mole at standard conditions, as defined in §98.6).

44/12 = Ratio of molecular weights, CO₂ to carbon.

0.001 = Conversion factor from kg to metric tons.

(iv) Fuel flow meters that measure mass flow rates may be used for liquid fuels, provided that the fuel density is used to convert the readings to volumetric flow rates. The density shall be measured at the same frequency as the carbon content, using ASTM D1298-99 (Reapproved 2005) "Standard Test Method for Density, Relative Density (Specific Gravity), or API Gravity of Crude Petroleum and Liquid Petroleum Products by Hydrometer Method" (incorporated by reference, see §98.7).

(v) The following default density values may be used for fuel oil, in lieu of using the ASTM method in paragraph (a)(3)(iv) of this section: 6.8 lb/gal for No. 1 oil; 7.2 lb/gal for No. 2 oil; 8.1 lb/gal for No. 6 oil.

(4) *Tier 4 Calculation Methodology.* Calculate the annual CO₂ mass emissions from all fuels combusted in a unit, by using quality-assured data from continuous emission monitoring systems (CEMS).

(i) This methodology requires a CO₂ concentration monitor and a stack gas

volumetric flow rate monitor, except as otherwise provided in paragraph (a)(4)(iv) of this section. Hourly measurements of CO₂ concentration and stack gas flow rate are converted to CO₂ mass emission rates in metric tons per hour.

(ii) When the CO₂ concentration is measured on a wet basis, Equation C-6 of this section is used to calculate the hourly CO₂ emission rates:

$$CO_2 = 5.18 \times 10^{-7} * C_{CO_2} * Q \quad (\text{Eq. C-6})$$

Where:

CO₂ = CO₂ mass emission rate (metric tons/hr).

C_{CO₂} = Hourly average CO₂ concentration (% CO₂).

Q = Hourly average stack gas volumetric flow rate (scfh).

5.18 × 10⁻⁷ = Conversion factor (metric tons/scf/% CO₂).

(iii) If the CO₂ concentration is measured on a dry basis, a correction for the stack gas moisture content is required. You shall either continuously monitor the stack gas moisture content as described in §75.11(b)(2) of this chapter or, for certain types of fuel, use a default moisture percentage from §75.11(b)(1) of this chapter. For each unit operating hour, a moisture correction must be applied to Equation C-6 of this section as follows:

$$CO_2^* = CO_2 \left(\frac{100 - \%H_2O}{100} \right) \quad (\text{Eq. C-7})$$

Where:

CO₂* = Hourly CO₂ mass emission rate, corrected for moisture (metric tons/hr).

CO₂ = Hourly CO₂ mass emission rate from Equation C-6 of this section, uncorrected (metric tons/hr).

%H₂O = Hourly moisture percentage in the stack gas (measured or default value, as appropriate).

(iv) An oxygen (O₂) concentration monitor may be used in lieu of a CO₂ concentration monitor to determine the hourly CO₂ concentrations, in accordance with Equation F-14a or F-14b (as applicable) in appendix F to 40 CFR part 75, if the effluent gas stream monitored by the CEMS consists solely of combustion products (i.e., no process CO₂ emissions are mixed with the combustion products) and if only fuels that are listed in Table 1 in section 3.3.5 of

appendix F to 40 CFR part 75 are combusted in the unit. If the O₂ monitoring option is selected, the F-factors used in Equations F-14a and F-14b shall be determined according to section 3.3.5 or section 3.3.6 of appendix F to 40 CFR part 75, as applicable. If Equation F-14b is used, the hourly moisture percentage in the stack gas shall be either a measured value in accordance with §75.11(b)(2) of this chapter, or, for certain types of fuel, a default moisture value from §75.11(b)(1) of this chapter.

(v) Each hourly CO₂ mass emission rate from Equation C-6 or C-7 of this section is multiplied by the operating time to convert it from metric tons per hour to metric tons. The operating time is the fraction of the hour during which fuel is combusted (e.g., the unit operating time is 1.0 if the unit operates for the whole hour and is 0.5 if the unit operates for 30 minutes in the hour). For common stack configurations, the operating time is the fraction of the hour during which effluent gases flow through the common stack.

(vi) The hourly CO₂ mass emissions are then summed over each calendar quarter and the quarterly totals are summed to determine the annual CO₂ mass emissions.

(vii) If both biomass and fossil fuel are combusted during the year, determine and report the biogenic CO₂ mass emissions separately, as described in paragraph (e) of this section.

(5) *Alternative methods for units with continuous monitoring systems.* Units not subject to the Acid Rain Program that report data to EPA according to 40 CFR part 75 may use the alternative methods in this paragraph in lieu of using any of the four calculation methodology tiers.

(i) For a unit that combusts only natural gas and/or fuel oil, is not subject to the Acid Rain Program, monitors and reports heat input data year-round according to appendix D to 40 CFR part 75, but is not required by the applicable 40 CFR part 75 program to report CO₂ mass emissions data, calculate the annual CO₂ mass emissions for the purposes of this part as follows:

(A) Use the hourly heat input data from appendix D to 40 CFR part 75, together with Equation G-4 in appendix G to 40 CFR part 75 to determine the

hourly CO₂ mass emission rates, in units of tons/hr;

(B) Use Equations F-12 and F-13 in appendix F to 40 CFR part 75 to calculate the quarterly and cumulative annual CO₂ mass emissions, respectively, in units of short tons; and

(C) Divide the cumulative annual CO₂ mass emissions value by 1.1 to convert it to metric tons.

(ii) For a unit that combusts only natural gas and/or fuel oil, is not subject to the Acid Rain Program, monitors and reports heat input data year-round according to 40 CFR 75.19 of this chapter but is not required by the applicable 40 CFR part 75 program to report CO₂ mass emissions data, calculate the annual CO₂ mass emissions for the purposes of this part as follows:

(A) Calculate the hourly CO₂ mass emissions, in units of short tons, using Equation LM-11 in 40 CFR 75.19(c)(4)(iii).

(B) Sum the hourly CO₂ mass emissions values over the entire reporting year to obtain the cumulative annual CO₂ mass emissions, in units of short tons.

(C) Divide the cumulative annual CO₂ mass emissions value by 1.1 to convert it to metric tons.

(iii) For a unit that is not subject to the Acid Rain Program, uses flow rate and CO₂ (or O₂) CEMS to report heat input data year-round according to 40 CFR part 75, but is not required by the applicable 40 CFR part 75 program to report CO₂ mass emissions data, calculate the annual CO₂ mass emissions as follows:

(A) Use Equation F-11 or F-2 (as applicable) in appendix F to 40 CFR part 75 to calculate the hourly CO₂ mass emission rates from the CEMS data. If an O₂ monitor is used, convert the hourly average O₂ readings to CO₂ using Equation F-14a or F-14b in appendix F to 40 CFR part 75 (as applicable), before applying Equation F-11 or F-2.

(B) Use Equations F-12 and F-13 in appendix F to 40 CFR part 75 to calculate the quarterly and cumulative annual CO₂ mass emissions, respectively, in units of short tons.

(C) Divide the cumulative annual CO₂ mass emissions value by 1.1 to convert it to metric tons.

(D) If both biomass and fossil fuel are combusted during the year, determine and report the biogenic CO₂ mass emissions separately, as described in paragraph (e) of this section.

(b) *Use of the four tiers.* Use of the four tiers of CO₂ emissions calculation methodologies described in paragraph (a) of this section is subject to the following conditions, requirements, and restrictions:

(1) The Tier 1 Calculation Methodology:

(i) May be used for any fuel listed in Table C-1 of this subpart that is combusted in a unit with a maximum rated heat input capacity of 250 mmBtu/hr or less.

(ii) May be used for MSW in a unit of any size that does not produce steam, if the use of Tier 4 is not required.

(iii) May be used for solid, gaseous, or liquid biomass fuels in a unit of any size provided that the fuel is listed in Table C-1 of this subpart.

(iv) May not be used if you routinely perform fuel sampling and analysis for the fuel high heat value (HHV) or routinely receive the results of HHV sampling and analysis from the fuel supplier at the minimum frequency specified in § 98.34(a), or at a greater frequency. In such cases, Tier 2 shall be used.

(2) The Tier 2 Calculation Methodology:

(i) May be used for the combustion of any type of fuel in a unit with a maximum rated heat input capacity of 250 mmBtu/hr or less provided that the fuel is listed in Table C-1 of this subpart.

(ii) May be used in a unit with a maximum rated heat input capacity greater than 250 mmBtu/hr for the combustion of pipeline quality natural gas and distillate fuel oil.

(iii) May be used for MSW in a unit of any size that produces steam, if the use of Tier 4 is not required.

(3) The Tier 3 Calculation Methodology:

(i) May be used for a unit of any size that combusts any type of fuel listed in Table C-1 of this subpart (except for MSW), unless the use of Tier 4 is required.

(ii) Shall be used for a unit with a maximum rated heat input capacity

greater than 250 mmBtu/hr that combusts any type of fuel listed in Table C-1 of this subpart (except MSW), unless either of the following conditions apply:

(A) The use of Tier 1 or 2 is permitted, as described in paragraphs (b)(1)(iii) and (b)(2)(ii) of this section.

(B) The use of Tier 4 is required.

(iii) Shall be used for a fuel not listed in Table C-1 of this subpart if the fuel is combusted in a unit with a maximum rated heat input capacity greater than 250 mmBtu/hr provided that both of the following conditions apply:

(A) The use of Tier 4 is not required.

(B) The fuel provides 10% or more of the annual heat input to the unit or, if §98.36(c)(3) applies, to a group of units served by common supply pipe.

(4) The Tier 4 Calculation Methodology:

(i) May be used for a unit of any size, combusting any type of fuel.

(ii) Shall be used if the unit meets all six of the conditions specified in paragraphs (b)(4)(ii)(A) through (b)(4)(ii)(F) of this section:

(A) The unit has a maximum rated heat input capacity greater than 250 mmBtu/hr, or if the unit combusts municipal solid waste and has a maximum rated input capacity greater than 250 tons per day of MSW.

(B) The unit combusts solid fossil fuel or MSW, either as a primary or secondary fuel.

(C) The unit has operated for more than 1,000 hours in any calendar year since 2005.

(D) The unit has installed CEMS that are required either by an applicable Federal or State regulation or the unit's operating permit.

(E) The installed CEMS include a gas monitor of any kind or a stack gas volumetric flow rate monitor, or both and the monitors have been certified, either in accordance with the requirements of 40 CFR part 75, part 60 of this chapter, or an applicable State continuous monitoring program.

(F) The installed gas or stack gas volumetric flow rate monitors are required, either by an applicable Federal or State regulation or by the unit's operating permit, to undergo periodic quality assurance testing in accordance with either appendix B to 40 CFR

part 75, appendix F to 40 CFR part 60, or an applicable State continuous monitoring program.

(iii) Shall be used for a unit with a maximum rated heat input capacity of 250 mmBtu/hr or less and for a unit that combusts municipal solid waste with a maximum rated input capacity of 250 tons of MSW per day or less, if the unit meets all of the following three conditions:

(A) The unit has both a stack gas volumetric flow rate monitor and a CO₂ concentration monitor.

(B) The unit meets the conditions specified in paragraphs (b)(4)(ii)(B) through (b)(4)(ii)(D) of this section.

(C) The CO₂ and stack gas volumetric flow rate monitors meet the conditions specified in paragraphs (b)(4)(ii)(E) and (b)(4)(ii)(F) of this section.

(5) The Tier 4 Calculation Methodology shall be used beginning on:

(i) January 1, 2010, for a unit that is required to report CO₂ mass emissions beginning on that date, if all of the monitors needed to measure CO₂ mass emissions have been installed and certified by that date.

(ii) January 1, 2011, for a unit that is required to report CO₂ mass emissions beginning on January 1, 2010, if all of the monitors needed to measure CO₂ mass emissions have not been installed and certified by January 1, 2010. In this case, you may use Tier 2 or Tier 3 to report GHG emissions for 2010.

(6) You may elect to use any applicable higher tier for one or more of the fuels combusted in a unit. For example, if a 100 mmBtu/hr unit combusts natural gas and distillate fuel oil, you may elect to use Tier 1 for natural gas and Tier 3 for the fuel oil, even though Tier 1 could have been used for both fuels. However, for units that use either the Tier 4 or the alternative calculation methodology specified in paragraph (a)(5) of this section, CO₂ emissions from the combustion of all fuels shall be based solely on CEMS measurements.

(c) *Calculation of CH₄ and N₂O emissions from stationary combustion sources.* You must calculate annual CH₄ and N₂O mass emissions only for units that are required to report CO₂ emissions using the calculation methodologies of this subpart and for only those fuels

Environmental Protection Agency**§ 98.33**

that are listed in Table C-2 of this subpart.

(1) Use Equation C-8 of this section to estimate CH₄ and N₂O emissions for any fuels for which you use the Tier 1

or Tier 3 calculation methodologies for CO₂. Use the same values for fuel combustion that you use for the Tier 1 or Tier 3 calculation.

$$CH_4 \text{ or } N_2O = 1 \times 10^{-3} * Fuel * HHV * EF \quad (\text{Eq. C-8})$$

Where:

CH₄ or N₂O = Annual CH₄ or N₂O emissions from the combustion of a particular type of fuel (metric tons).

Fuel = Mass or volume of the fuel combusted, either from company records or directly measured by a fuel flow meter, as applicable (mass or volume per year).

HHV = Default high heat value of the fuel from Table C-1 of this subpart (mmBtu per mass or volume).

EF = Fuel-specific default emission factor for CH₄ or N₂O, from Table C-2 of this subpart (kg CH₄ or N₂O per mmBtu).

1 × 10⁻³ = Conversion factor from kilograms to metric tons.

(2) Use Equation C-9a of this section to estimate CH₄ and N₂O emissions for any fuels for which you use the Tier 2 Equation C-2a of this section to estimate CO₂ emissions. Use the same values for fuel combustion and HHV that you use for the Tier 1 or Tier 3 calculation.

$$CH_4 \text{ or } N_2O = 1 \times 10^{-3} * HHV * EF * Fuel \quad (\text{Eq. C-9a})$$

Where:

CH₄ or N₂O = Annual CH₄ or N₂O emissions from the combustion of a particular type of fuel (metric tons).

Fuel = Mass or volume of the fuel combusted during the reporting year.

HHV = High heat value of the fuel, averaged for all valid measurements for the reporting year (mmBtu per mass or volume).

EF = Fuel-specific default emission factor for CH₄ or N₂O, from Table C-2 of this subpart (kg CH₄ or N₂O per mmBtu).

1 × 10⁻³ = Conversion factor from kilograms to metric tons.

(3) Use Equation C-9b of this section to estimate CH₄ and N₂O emissions for any fuels for which you use Equation C-2c of this section to calculate the CO₂ emissions. Use the same values for steam generation and the ratio “B” that you use for Equation C-2c.

$$CH_4 \text{ or } N_2O = 1 \times 10^{-3} * Steam * B * EF \quad (\text{Eq. C-9b})$$

Where:

CH₄ or N₂O = Annual CH₄ or N₂O emissions from the combustion of a solid fuel (metric tons).

Steam = Total mass of steam generated by solid fuel combustion during the reporting year (lb steam).

B = Ratio of the boiler’s maximum rated heat input capacity to its design rated steam output (mmBtu/lb steam).

EF = Fuel-specific emission factor for CH₄ or N₂O, from Table C-2 of this subpart (kg CH₄ or N₂O per mmBtu).

1 × 10⁻³ = Conversion factor from kilograms to metric tons.

(4) Use Equation C-10 of this section for units in the Acid Rain Program, units that monitor and report heat input on a year-round basis according to 40 CFR part 75, and units that use the Tier 4 Calculation Methodology.

$$\text{CH}_4 \text{ or N}_2\text{O} = 0.001 * (\text{HI})_A * \text{EF} \quad (\text{Eq. C-10})$$

Where:

CH₄ or N₂O = Annual CH₄ or N₂O emissions from the combustion of a particular type of fuel (metric tons).

(HI)_A = Cumulative annual heat input from the fuel, derived from the electronic data reports required under § 75.64 of this chapter or, for Tier 4 units, from the best available information as described in paragraph (c)(4)(ii) of this section (mmBtu).

EF = Fuel-specific emission factor for CH₄ or N₂O, from Table C-2 of this section (kg CH₄ or N₂O per mmBtu).

0.001 = Conversion factor from kg to metric tons.

(i) If only one type of fuel listed in Table C-2 of this subpart is combusted during normal operation, substitute the cumulative annual heat input from combustion of the fuel into Equation C-10 of this section to calculate the annual CH₄ or N₂O emissions.

(ii) If more than one type of fuel listed in Table C-2 of this subpart is combusted during normal operation, use Equation C-10 of this section sepa-

ately for each type of fuel. If flow rate and diluent gas monitors are used to measure the unit heat input, use the best available information (e.g., fuel feed rate measurements, fuel heating values, engineering analysis) to estimate the annual heat input from each type of fuel.

(5) When multiple fuels are combusted during the reporting year, sum the fuel-specific results from Equations C-8, C-9a, C-9b, or C-10 of this section (as applicable) to obtain the total annual CH₄ and N₂O emissions, in metric tons.

(d) *Calculation of CO₂ from sorbent.* (1) When a unit is a fluidized bed boiler, is equipped with a wet flue gas desulfurization system, or uses other acid gas emission controls with sorbent injection, use Equation C-11 of this section to calculate the CO₂ emissions from the sorbent, if those CO₂ emissions are not monitored by CEMS:

$$\text{CO}_2 = 0.91 * S * R * \left(\frac{\text{MW}_{\text{CO}_2}}{\text{MW}_S} \right) \quad (\text{Eq. C-11})$$

Where:

CO₂ = CO₂ emitted from sorbent for the reporting year (metric tons).

S = Limestone or other sorbent used in the reporting year, from company records (short tons).

R = 1.00, the calcium-to-sulfur stoichiometric ratio.

MW_{CO₂} = Molecular weight of carbon dioxide (44).

MW_S = Molecular weight of sorbent (100 if calcium carbonate).

0.91 = Conversion factor from short tons to metric tons.

(2) The annual CO₂ mass emissions for the unit shall be the sum of the CO₂ emissions from the combustion process and the CO₂ emissions from the sorbent.

(e) *CO₂ emissions from combustion of biomass.* Use the procedures of this paragraph (e) to estimate biogenic CO₂ emissions from units that combust a

combination of biomass and fossil fuels. Reporting of CO₂ emissions from combustion of biomass is required only for those biomass fuels listed in Table C-1 of this section, unless emissions are measured using CEMS.

(1) If CEMS are not used to measure CO₂, use Equation C-1 of this subpart to calculate the annual CO₂ mass emissions from the combustion of biomass (except MSW) for a unit of any size. Determine the mass of biomass combusted using one of the following procedures in this paragraph (e)(1), as appropriate.

(i) Use company records.

(ii) Follow the procedures in paragraph (e)(5) of this section.

(iii) For premixed fuels that contain biomass and fossil fuels (e.g., mixtures containing biodiesel), use best available information to determine the

Environmental Protection Agency

§ 98.33

mass of biomass fuels and document the procedure used in the GHG Monitoring Plan required by § 98.3(g)(5).

(2) If a CO₂ CEMS (or a surrogate O₂ monitor) and a stack gas flow rate monitor are used to determine the annual CO₂ mass emissions either according to 40 CFR part 75, the Tier 4 Calculation Methodology, or the alternative calculation methodology specified in paragraph (a)(5)(iii); and if both

fossil fuel and biomass (except for MSW) are combusted in the unit during the reporting year, you may use the following procedure to determine the annual biogenic CO₂ mass emissions. If MSW is combusted in the unit, follow the procedures in paragraph (e)(3) of this section.

(i) For each operating hour, use Equation C-12 of this section to determine the volume of CO₂ emitted.

$$V_{CO2h} = \frac{(\%CO_2)_h}{100} * Q_h * t_h \quad (\text{Eq. C-12})$$

Where:

- V_{CO2h} = Hourly volume of CO₂ emitted (scf).
- (%CO₂)_h = Hourly average CO₂ concentration, measured by the CO₂ concentration monitor, or, if applicable, calculated from the hourly average O₂ concentration (%CO₂).
- Q_h = Hourly average stack gas volumetric flow rate, measured by the stack gas volumetric flow rate monitor (scfh).
- t_h = Source operating time (decimal fraction of the hour during which the source combusts fuel, i.e., 1.0 for a full operating hour, 0.5 for 30 minutes of operation, etc.).
- 100 = Conversion factor from percent to a decimal fraction.

(ii) Sum all of the hourly V_{CO2h} values for the reporting year, to obtain V_{total}, the total annual volume of CO₂ emitted.

(iii) Calculate the annual volume of CO₂ emitted from fossil fuel combustion using Equation C-13 of this section. If two or more types of fossil fuel are combusted during the year, perform a separate calculation with Equation C-13 of this section for each fuel and sum the results.

$$V_{ff} = \frac{\text{Fuel} * F_c * \text{HHV}}{10^6} \quad (\text{Eq. C-13})$$

Where:

- V_{ff} = Annual volume of CO₂ emitted from combustion of a particular fossil fuel (scf).
- Fuel = Total quantity of the fossil fuel combusted in the reporting year, from company records, as defined in § 98.6 (lb for solid fuel, gallons for liquid fuel, and scf for gaseous fuel).
- F_c = Fuel-specific carbon based F-factor, either a default value from Table 1 in section 3.3.5 of appendix F to 40 CFR part 75 or a

site-specific value determined under section 3.3.6 of appendix F to 40 CFR part 75 (scf CO₂/mmBtu).

HHV = High heat value of the fossil fuel, from fuel sampling and analysis (annual average value in Btu/lb for solid fuel, Btu/gal for liquid fuel and Btu/scf for gaseous fuel, sampled as specified (e.g., monthly, quarterly, semi-annually, or by lot) in § 98.34(a)(2)). The average HHV shall be calculated according to the requirements of paragraph (a)(2)(ii) of this section.

10⁶ = Conversion factor, Btu per mmBtu.

(iv) Subtract V_{ff} from V_{total} to obtain V_{bio}, the annual volume of CO₂ from the combustion of biomass. If a CEMS is being used to measure the combined combustion and process emissions from a unit that is subject to another subpart of part 98, then also subtract CO₂ process emissions from V_{total} to determine V_{bio}. The CO₂ process emissions must be calculated according to the requirements of the applicable subpart.

(v) Calculate the biogenic percentage of the annual CO₂ emissions, expressed as a decimal fraction, using Equation C-14 of this section:

$$\% \text{ Biogenic} = \frac{V_{bio}}{V_{total}} \quad (\text{Eq. C-14})$$

(vi) Calculate the annual biogenic CO₂ mass emissions, in metric tons, by multiplying the results obtained from Equation C-14 of this section by the annual CO₂ mass emissions in metric tons, as determined:

(A) Under paragraph (a)(4)(vi) of this section, for units using the Tier 4 Calculation Methodology.

(B) Under paragraph (a)(5)(iii)(B) of this section, for units using the alternative calculation methodology specified in paragraph (a)(5)(iii).

(C) From the electronic data report required under § 75.64 of this chapter, for units in the Acid Rain Program and other units using CEMS to monitor and report CO₂ mass emissions according to 40 CFR part 75. However, before calculating the annual biogenic CO₂ mass emissions, multiply the cumulative annual CO₂ mass emissions by 0.91 to convert from short tons to metric tons.

(3) For a unit that combusts MSW, the annual biogenic CO₂ emissions shall be calculated using the procedures in this paragraph (e)(3).

(i) If the Tier 1 or Tier 2 Calculation Methodology is used to quantify CO₂ mass emissions:

(A) Use Equation C-1 or C-2c of this subpart, as appropriate, to calculate the annual CO₂ mass emissions from MSW combustion.

(B) Determine the relative proportions of biogenic and non-biogenic CO₂ emissions on a quarterly basis using the method specified in § 98.34(d).

(C) Determine the annual biogenic CO₂ mass emissions from MSW combustion by multiplying the annual CO₂ mass emissions by the annual average biogenic decimal fraction obtained from § 98.34(d).

(ii) If the unit uses Tier 4 to quantify CO₂ emissions:

(A) Follow the procedures in paragraphs (e)(2)(i) and (ii) of this section, to determine V_{total}.

(B) If any fossil fuel was combusted during the year, follow the procedures in paragraph (e)(2)(iii) of this section, to determine V_{ff}.

(C) Subtract V_{ff} from V_{total}, to obtain V_{MSW}, the annual volume of CO₂ emissions from MSW combustion.

(D) Determine the annual volume of biogenic CO₂ emissions (V_{bio}) from

MSW combustion as follows. Multiply the annual volume of CO₂ emissions from MSW combustion (V_{MSW}) by the annual average biogenic decimal fraction obtained from ASTM D6866-08 and ASTM D7459-08.

(E) Calculate the biogenic percentage of the annual CO₂ emissions from the unit, using Equation C-14 of this section. For the purposes of this calculation, the term “V_{bio}” in the numerator of Equation C-14 of this section shall be the results of the calculation performed under paragraph (e)(3)(ii)(D) of this section.

(F) Calculate the annual biogenic CO₂ mass emissions according to paragraph (e)(2)(vi)(A) of this section.

(4) As an alternative to the procedures in paragraph (e)(2) of this section, use ASTM Methods D7459-08 and D6866-08 to determine the biogenic portion of the annual CO₂ emissions, as described in § 98.34(e). If this option is selected, the results of each determination shall be expressed as a decimal fraction (e.g., 0.30, if 30 percent of the CO₂ is biogenic), and the values shall be averaged over the reporting year. The annual biogenic CO₂ mass emissions shall be calculated by multiplying the total annual CO₂ mass emissions by the annual average biogenic fraction obtained from ASTM D6866-08 and ASTM D7459-08.

(5) If Equation C-1 of this section is selected to calculate the annual biogenic mass emissions for wood, wood waste, or other solid biomass-derived fuel, Equation C-15 of this section may be used to quantify biogenic fuel consumption, provided that all of the required input parameters are accurately quantified. Similar equations and calculation methodologies based on steam generation and boiler efficiency may be used, provided that they are documented in the GHG Monitoring Plan required by § 98.3(g)(5).

$$(Fuel)_p = \frac{[H * S] - (HI)_{nb}}{2000 (HHV)_{bio} (Eff)_{bio}} \quad (\text{Eq. C-15})$$

Where:

(Fuel)_p = Quantity of biomass consumed during the measurement period "p" (tons/year or tons/month, as applicable).

H = Average enthalpy of the boiler steam for the measurement period (Btu/lb).

S = Total boiler steam production for the measurement period (lb/month or lb/year, as applicable).

(HI)_{nb} = Heat input from co-fired fossil fuels and non-biomass-derived fuels for the measurement period, based on company records of fuel usage and default or measured HHV values (Btu/month or Btu/year, as applicable).

(HHV)_{bio} = Default or measured high heat value of the biomass fuel (Btu/lb).

(Eff)_{bio} = Percent efficiency of biomass-to-energy conversion, expressed as a decimal fraction.

2000 = Conversion factor (lb/ton).

§ 98.34 Monitoring and QA/QC requirements.

The CO₂ mass emissions data for stationary fuel combustion sources shall be monitored as follows:

(a) For the Tier 2 Calculation Methodology:

(1) All fuel samples shall be taken at a location in the fuel handling system that provides a sample representative of the fuel combusted. The fuel sampling and analysis may be performed by either the owner or operator or the supplier of the fuel.

(2) The minimum required frequency of the HHV sampling and analysis for each type of fuel is specified in this paragraph. When the specified frequency is based on a specified time period (i.e., weekly, monthly, quarterly, or semiannually), fuel sampling and analysis is required only for those periods in which the unit operates.

(i) For natural gas, semiannual sampling and analysis is required (i.e., twice in a calendar year, with consecutive samples taken at least four months apart).

(ii) For coal and fuel oil, analysis of at least one representative sample from each fuel lot is required. For the purposes of this section, a fuel lot is defined as a shipment or delivery of a single fuel (e.g., ship load, barge load, group of trucks, group of railroad cars, etc.).

(iii) For liquid fuels other than fuel oil, for fossil fuel-derived gaseous fuels, and for biogas; sampling and analysis

is required at least once per calendar quarter. To the extent practicable, consecutive quarterly samples shall be taken at least 30 days apart.

(iv) For solid fuels other than coal and MSW, weekly sampling is required to obtain composite samples, which are then analyzed monthly.

(3) If different types of fuel (e.g., different ranks of coal or different grades of fuel oil) are blended prior to combustion, use one of the following procedures in this paragraph.

(i) Use a weighted HHV value in the emission calculations, based on the relative proportions of each fuel in the blend.

(ii) Take a representative sample of the blend and analyze it for HHV.

(4) If, for a particular type of fuel, HHV sampling and analysis is performed more often than the minimum frequency specified in paragraph (a)(2) of this section, the results of all valid fuel analyses shall be used in the GHG emission calculations.

(5) If, for a particular type of fuel, valid HHV values are obtained at less than the minimum frequency specified in paragraph (a)(2) of this section, appropriate substitute data values shall be used in the emissions calculations, in accordance with missing data procedures of § 98.35.

(6) Use any applicable fuel sampling and analysis methods in this paragraph (a)(6) to determine the high heat values. Alternatively, for gaseous fuels, the HHV may be calculated using chromatographic analysis together with standard heating values of the fuel constituents, provided that the gas chromatograph is operated, maintained, and calibrated according to the manufacturer's instructions.

(i) ASTM D4809-06 Standard Test Method for Heat of Combustion of Liquid Hydrocarbon Fuels by Bomb Calorimeter (Precision Method) (incorporated by reference, see § 98.7).

(ii) ASTM D240-02 (Reapproved 2007) Standard Test Method for Heat of Combustion of Liquid Hydrocarbon Fuels by Bomb Calorimeter (incorporated by reference, see § 98.7).

(iii) ASTM D1826-94 (Reapproved 2003) Standard Test Method for Calorific (Heating) Value of Gases in Natural Gas Range by Continuous Recording