

(b) Each semiportable fire extinguisher must be mounted or otherwise placed in the open so as to be readily visible.

(c) Except as provided by paragraph (d) of this section, each portable fire extinguisher must be mounted or otherwise placed in the open or behind glass so as to be readily visible.

(d) A portable fire extinguisher may be mounted or otherwise placed in an enclosure together with the fire hose, if the enclosure is marked in compliance with § 131.830 of this subchapter.

(e) Each portable fire extinguisher and its station must be numbered to comply with § 131.835 of this subchapter.

(f) No portable or semiportable fire extinguisher with a nameplate indicating that it needs protection from freezing may be mounted or otherwise placed where freezing temperatures are foreseeable.

#### § 132.230 Spare charges.

(a) Except as provided by paragraph (b) or (c) of this section, each vessel must carry spare charges for 50 percent of the portable fire extinguishers required by § 132.220 of this subpart.

(b) Rather than comply with paragraph (a) of this section, a vessel may carry one extra portable extinguisher of the same classification.

(c) If extinguishers of a particular classification cannot be readily recharged by crew members, a vessel must—rather than comply with paragraph (a) of this section—carry one more extinguisher of that classification.

(d) Each spare charge must be packaged so as to minimize the hazards to personnel recharging the extinguishers.

#### § 132.240 Stowage of semiportable fire extinguishers.

The frame or support of each semiportable fire extinguisher of size III, IV, or V must be secured to prevent the extinguisher from shifting in heavy weather.

### Subpart C—Miscellaneous

#### § 132.310 Fixed fire-extinguishing systems for paint lockers.

(a) Except as provided by paragraph (b) of this section, a fixed gaseous fire-extinguishing system or another approved fixed fire-extinguishing system must be installed in each paint locker.

(b) No fixed fire-extinguishing system need be installed in a paint locker that is—

(1) Less than 1.7 cubic meters (60 cubic feet) in volume;

(2) Accessible only from the weather deck; and

(3) Not adjacent to a tank for flammable or combustible liquid.

(c) Each fixed fire-extinguishing system installed must comply with part 95 of this chapter or be approved by the Commanding Officer, Marine Safety Center.

#### § 132.320 Helicopter-landing decks.

Each vessel with a helicopter-landing deck must meet the fire fighting requirements of part 108 of this chapter.

#### § 132.330 Fire monitors.

(a) Each fire monitor of the fire main system must be fitted with a shut-off valve at the monitor and at the connection to the fire main discharge manifold required by § 132.120(h) of this part.

(b) Fire monitor piping must comply with § 132.110 of this part.

(c) Each fire monitor must be protected against over-pressure.

#### § 132.340 Equipment installed although not required.

A vessel may install equipment for detection of and protection against fires beyond that required by this subchapter, unless the excess equipment in any way endangers the vessel or the persons aboard. This equipment must be listed and labeled by a nationally recognized testing laboratory.

#### § 132.350 Tests and inspections of fire-extinguishing equipment.

(a) Each master of a vessel shall ensure that the tests and inspections, of fire-extinguishing equipment, described by paragraph (b) of this section are performed—