

§ 117.107

full open position at which time they will change to steady green.

(f) The bridge can also be operated from two locked trackside control location (key releases) on the approach spans, one on each side of the movable span.

(g) To request openings of the bridge when the lift span is in the closed-to-navigation position, mariners may contact the AGR via VHF-FM channel 16 or by telephone at 205-654-4364.

[USCG-2012-0764, 77 FR 57028, Sept. 17, 2012]

§ 117.107 Chattahoochee River.

The draws of the CSX Transportation Railroad bridge, mile 117.1 near Omaha, GA, shall open on signal if at least six hours notice is given.

§ 117.109 Coosa River.

The draw of the CSX Transportation Railroad bridge, mile 175.0 at Gadsden, shall open on signal if at least six hours notice is given.

§ 117.113 Tensaw River.

The draw of the CSX Transportation Railroad bridge, mile 15.0 at Hurricane, shall open on signal; except that, from 5 p.m. to 9 a.m., the draw shall open on signal if at least eight hours notice is given. During periods of severe storms or hurricanes, from the time the National Weather Service sounds an "alert" for the area until the "all clear" is sounded, the draw shall open on signal.

[CGD8-85-09, 50 FR 37356, Sept. 13, 1985]

§ 117.115 Three Mile Creek.

(a) The draw of the US43 bridge, mile 1.0 at Mobile, need not be opened from 7 a.m. to 9 a.m. and from 4:30 p.m. to 6:30 p.m. daily. At all other times, the draw shall open on signal if at least 12 hours notice is given.

(b) The draw of the Norfolk Southern railroad bridge, mile 1.1 at Mobile, shall open on signal if at least five days notice is given.

§ 117.118 Tombigbee River.

The draw of the Meridian and Bigbee Railroad (MNBR) vertical lift span bridge across the Tombigbee River, mile 128.6 (Black Warrior Tombigbee

33 CFR Ch. I (7-1-13 Edition)

(BWT) Waterway mile 173.6), at Naheola, shall operate as follows:

(a) The draw shall be maintained in the fully open-to-navigation position for vessels at all times, except during periods when it is closed for the passage of rail traffic.

(b) When a train approaches the bridge, it will stop and a crewmember from the train will observe the waterway for approaching vessels. If vessels are observed approaching the bridge, they will be allowed to pass prior to lowering the bridge. The crewmember will then announce via radiotelephone on VHF-FM channel 16 that the bridge is preparing to be lowered. If, after two minutes, no response has been received, the crewmember will initiate the lowering sequence.

(c) After the train has completely passed over the bridge, the crewmember will initiate the raising sequence. When the bridge is in the fully open-to-navigation position, the crewmember will announce via radiotelephone on VHF-FM channel 16 that the bridge is in the fully open-to-navigation position.

(d) To request openings of the bridge when the lift span is in the closed-to-navigation position, mariners may contact the MNBR via VHF-FM channel 16 or by telephone at 205-654-4364.

[USCG-2012-0179, 77 FR 57026, Sept. 17, 2012]

ARKANSAS

§ 117.121 Arkansas River.

The draw of the Missouri Pacific Railroad bridge, mile 23.1 near Yancopin, shall open on signal if at least 96 hours notice is given.

§ 117.123 Arkansas Waterway.

(a) Across the Arkansas Waterway, the draw of the Rob Roy Drawbridge, mile 67.4, at Pine Bluff, Arkansas is maintained in the closed to navigation position and is remotely operated. Any vessel which requires an opening of the draw of this bridge shall establish contact by radiotelephone with the remote drawbridge operator on VHF-FM Channel 12 in Omaha, Nebraska. To establish contact, the vessel shall key the VHF-FM radio microphone four times in five seconds and listen for an acknowledgement tone. The remote