

§ 98.25-45

46 CFR Ch. I (10-1-14 Edition)

suitable valves installed at the loading header.

(i) Relief valves shall be fitted in liquid lines which may be subject to excessive pressure caused by liquid full condition, and the escape from the relief valves shall be piped to the venting system.

(j) The pressure gage shall be located at the highest practical point. The thermometer well shall terminate in the liquid space and be attached to the shell by welding with the end of the fitting being provided with a gas-tight screwed plug or bolted cover.

[CGFR 65-50, 30 FR 17022, Dec. 30, 1965, as amended by CGFR 68-82, 33 FR 18902, Dec. 18, 1968; CGFR 70-10, 35 FR 3712, Feb. 25, 1970]

§ 98.25-45 Liquid level gaging device.

(a) Each tank shall be fitted with a liquid level gaging device of suitable design to indicate the maximum level to which the tank may be filled with liquid at temperatures between 20 °F. and 130 °F.

(b) Liquid level gaging devices shall be of the following types: magnetic, rotary tube, slip tube, fixed tube, automatic float, or other types acceptable to the Commandant.

(c) Gaging devices that require bleeding of the product to the atmosphere, such as rotary tube, fixed tube, and slip tube, shall be so designed that the bleed valve maximum opening is not larger than a No. 54 drill size, unless provided with an excess flow valve.

(d) Gaging devices shall have a design pressure of at least 250 pounds per square inch.

(e) Gage glasses of the columnar type are prohibited.

§ 98.25-50 Filling and discharge pipes.

(a) Filling connections shall be provided with one of the following:

(1) Combination back pressure check valve and excess flow valve;

(2) One double or two single back pressure check valves; or

(3) A positive shut-off valve in conjunction with either an internal back pressure check valve or an internal excess flow valve.

(b) All other liquid and vapor connections to tanks, except filling connections, safety relief valves, and liquid level gaging devices and pressure gages

described in § 98.25-40(e) and (f) shall be equipped with automatic excess flow valves; or in lieu thereof, may be fitted with quick closing internal stop valves, which, except during filling and discharge operations, shall remain closed. The control mechanism for such valves shall be provided with a secondary remote control of a type acceptable to the Commandant.

(c) The excess flow, internal stop or back pressure check valves shall be located on the inside of the tank or outside where the piping enters the tank. In the latter case, installation shall be made in such a manner that any undue strain will not cause breakage between the tank and the excess flow or internal stop valve.

(d) Where the filling and discharge are made through a common nozzle at the tank, and the connection is fitted with a quick-closing internal stop valve as permitted in paragraph (b) of this section, the back pressure check valve or excess flow valve is not required, provided, however, a positive shut-off valve is installed in conjunction with the internal stop valve.

[CGFR 65-50, 30 FR 17022, Dec. 30, 1965, as amended by CGFR 70-10, 35 FR 3712, Feb. 25, 1970]

§ 98.25-55 Cargo piping.

(a) Piping shall be of seamless steel meeting the requirements of § 56.60-1 of subchapter F (Marine Engineering) of this chapter. The piping shall be of not less than Schedule 40 thickness. In case of piping on the discharge side of the liquid pumps or vapor compressors, the design shall be for a pressure of not less than the pump or compressor relief valve setting; or if the piping is not fitted with relief valves, the design pressure shall not be less than the total discharge head of the pump or compressor.

(b) Where necessary, provision shall be made for expansion and contraction of piping by means of seamless steel pipe expansion bends. Special consideration will be given for packless type expansion joints. Slip type expansion joints are prohibited. Piping shall be provided with adequate support to take

the weight of the piping off the valves and fittings.

[CGFR 65-50, 30 FR 17022, Dec. 30, 1965, as amended by CGFR 68-82, 33 FR 18902, Dec. 18, 1968]

§ 98.25-60 Safety relief valves.

(a) Each tank shall be fitted with two or more approved safety relief valves, designed, constructed, and flow-tested for capacity in conformance with subpart 162.018 of subchapter Q (Specifications) of this chapter.

(b) Each safety relief valve shall start to discharge at a pressure not in excess of the design pressure of the tank.

(c) Safety relief valves shall be attached to the tank near the highest point of the vapor space. Shutoff valves shall not be installed between the tanks and the safety relief valves, except manifolds for mounting multiple safety relief valves may be fitted with acceptable interlocking three-way valves so arranged at all times as to permit at any position of the three-way valve, an unrestricted flow of vapors through at least one port. When two safety relief valves are mounted in parallel on both the upper outlets of the three-way valve, the arrangement shall be such as to permit at least one safety relief valve to be operative at all times.

(d) Each safety valve shall be tested in the presence of a marine inspector at the site of installation before or after mounting prior to being placed in service. The tests shall prove that the safety relief valve will start to discharge at a pressure not in excess of the maximum allowable pressure of the tank.

[CGFR 68-82, 33 FR 18902, Dec. 18, 1968]

§ 98.25-65 Filling density.

(a) The filling density, or the percent ratio of the liquefied gas that may be loaded in the tank to the weight of the water the tank will hold at 60 °F., shall not exceed 56 percent for unlagged tanks and 58 percent for lagged or refrigerated tanks.

§ 98.25-70 Venting.

(a) Except as provided in paragraph (b) of this section, each safety valve in-

stalled on a cargo tank shall be connected to a branch vent of a venting system which shall be constructed so that the discharge of gas will be directed vertically upward to a point at least 10 feet above the weather deck or the top of any tank or house located above the weather deck.

(b) The capacity of branch vents or vent headers shall depend upon the number of cargo tanks connected to such branch or header as provided in Table 98.25-70(b).

TABLE 98.25-70(b)—CAPACITY OF BRANCH VENTS OR VENT HEADERS

Number of cargo tanks	Percent of total valve discharge
1 or 2	100
3	90
4	80
5	70
6 or more	60

(c) In addition to the requirement specified in paragraph (b) of this section, the size of the branch vents or vent headers shall be such that the back pressure in relief valve discharge lines shall not be more than 10 percent of the safety relief valve setting.

(d) Return bends and restrictive pipe fittings are prohibited. Vents and headers shall be so installed as to prevent stresses on safety relief valve mountings.

(e) When vent discharge risers are installed, they shall be so located as to provide protection against physical damage and be fitted with loose raincaps.

(f) No shut-off valve shall be fitted in the venting system between the safety relief valve and the vent outlets. Suitable provision shall be made for draining the venting system if liquid can collect therein.

[CGFR 65-50, 30 FR 17022, Dec. 30, 1965, as amended by CGFR 70-10, 35 FR 3712, Feb. 25, 1970; 35 FR 6431, Apr. 22, 1970]

§ 98.25-75 Ventilation.

(a) All enclosed spaces containing cargo tanks fitted with bottom outlet connections shall be provided with mechanical ventilation of sufficient capacity to assure a change of air every 3 minutes. Where cargo tanks are fitted