

§ 117.245

p.m., from November 1 through March 31, if at least 24 hours notice is given. [CGD05-06-044, 71 FR 53325, Sept. 11, 2006, as amended by USCG-2017-0162, 82 FR 50084, Oct. 30, 2017]

§ 117.245 Smyrna River.

The draw of the Delaware highway bridge, mile 4.0 at Flemings Landing, shall open on signal if at least 24 hours notice is given.

DISTRICT OF COLUMBIA

§ 117.253 Anacostia River.

(a) The draw of the Frederick Douglass Memorial (South Capitol Street) bridge, mile 1.2, need not be opened for the passage of vessels.

(b) The CSX Railroad Bridge, mile 3.4.

(1) The draw of the bridge to be operated by the controller at the Benning Yard office shall open on signal:

(i) At all times for public vessels of the United States, state and local government vessels, commercial vessels and any vessels in an emergency involving danger to life or property.

(ii) Between 9 a.m. and 12 p.m. and between 1 p.m. and 6 p.m. from May 15 through September 30.

(iii) Between 6 p.m. and 7 p.m. from May 15 through September 30 if notice is given to the controller at the Benning Yard office not later than 6 p.m. on the day for which the opening is requested.

(iv) At all other times, if at least 48 hours of notice is given to the controller at the Benning Yard Office.

(2) The CSX Railroad Bridge shall not be operated by the controller at the Benning Yard office in the event of failure or obstruction of the motion sensors, laser scanners, video cameras or marine-radio communications. In these situations, a bridge tender must be called to operate the bridge on-site.

(3) Except as provided in §117.31(b), opening of the draw shall not exceed ten minutes after clearance of rail traffic.

(4) A horn will sound one prolonged blast followed by one short blast to indicate that the CSX Railroad Bridge is moving to the full open position for vessel traffic. During open span movement, the channel traffic lights will

33 CFR Ch. I (7-1-20 Edition)

flash red until the bridge is in the full open position to vessels. In the full open position to vessels, the bridge channel traffic lights will flash green.

(5) A horn will sound five short blasts, the channel traffic lights will flash red, and an audio voice-warning device will announce bridge movement during closing span movement. Five short blasts of the horn will continue until the bridge is seated in and locked down. When the bridge is seated and in locked down position to vessels, the channel traffic lights will continue to flash red.

(6) The owners of the bridge shall provide and keep in good legible condition two board gauges painted white with black figures not less than six inches high to indicate the vertical clearance under the closed draw at all stages of the tide. The gauges shall be placed on the bridge so that they are plainly visible to the operator of any vessel approaching the bridge from either upstream or downstream.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984; 49 FR 37381, Sept. 24, 1984, as amended by CGD5-88-004, 53 FR 9627, Mar. 23, 1988; CGD05-95-081, 61 FR 57586, Nov. 7, 1996; CGD05-04-028, 69 FR 47773, Aug. 6, 2004; USCG-2011-0591, 77 FR 14970, Mar. 14, 2012; USCG 2018-0473, 83 FR 54248, Oct. 29, 2018]

§ 117.255 Potomac River.

(a) The draw of the Woodrow Wilson Memorial (I-95) bridge, mile 103.8, between Alexandria, Virginia, and Oxon Hill, Maryland—

(1) Shall open on signal at any time only for a vessel in distress, notwithstanding the provisions of §117.31.

(2) Shall open for the passage of a commercial vessel at any time except:

(i) From Monday through Friday (except Federal holidays), 5 a.m. to 8 p.m.

(ii) Saturday, Sunday, and Federal holidays, 2 p.m. to 7 p.m.

(3) Need not open for the passage of a commercial vessel under paragraph (a)(2) of this section unless—

(i) The owner or operator of the vessel provides the bridge tender with an estimate of the approximate time of that passage at least 12 hours in advance at (703) 836-2396; and

(ii) the owner or operator of the vessel notifies the bridge tender at least 4

Coast Guard, DHS

§ 117.261

hours in advance of the requested time for that passage.

(4) Shall open for the passage of a recreational vessel at any time except:

(i) Monday through Friday (except Federal holidays), 5 a.m. to 12 midnight;

(ii) Saturday, Sunday, and Federal holidays, 7 a.m. to 12 midnight, except as provided in paragraph (a)(4)(iii) of this section;

(iii) Notwithstanding paragraph (a)(4)(ii) of this section, the bridge may open beginning at 10 p.m. on Saturday, Sunday, or a Federal holiday for the passage of a recreational vessel if the owner or operator of the vessel notifies the Bridge Tender of the time of that passage by not later than 12 hours before that time.

(5) Need not open for the passage of a recreational vessel under paragraph (a)(4) of this section unless—

(i) The owner or operator of the vessel provides the bridge tender with an estimate of the approximate time of that passage at least 12 hours in advance at (703) 836-2396; and

(ii) the owner or operator of the vessel notifies the bridge tender at least 4 hours in advance of the requested time for that passage.

(6) A recreational vessel may pass through the drawspan at any time it is open for the passage of a commercial vessel.

(b) The draws of all other bridges need not be opened for the passage of vessels.

(c) This section is also issued under the authority of Pub. L. 102-587, 106 Stat. 5039.

[CGD 90-064, 57 FR 54178, Nov. 17, 1992, as amended by CGD05-06-083, 71 FR 51480, Aug. 30, 2006; USCG-2001-10881, 71 FR 70310, Dec. 4, 2006; 72 FR 50876, Sept. 5, 2007; USCG-2008-1216, 74 FR 31182, June 30, 2009]

FLORIDA

§ 117.258 Apalachicola River.

(a) The draw of the Apalachicola and Northern Railroad Bridge, mile 4.5 (GIWW mile 347.0 EHL), at Apalachicola, is maintained in the fully open-to-navigation position and untended. The bridge will not be returned to service until proper notification is published in the FEDERAL REGISTER.

(b) The draw of the CSX Railroad Bridge, mile 105.9, at River Junction shall open on signal if at least eight hours notice is given.

[USCG-2012-0470, 77 FR 75556, Dec. 21, 2012]

§ 117.261 Atlantic Intracoastal Waterway from St. Marys River to Key Largo.

(a) General. Public vessels of the United States and tugs with tows must be passed through the drawspan of each drawbridge listed in this section at anytime.

(b)-(c) [Reserved]

(d) Bridge of Lions (SR A1A) bridge, mile 777.9 at St. Augustine. The draw shall open on signal; except that, from 7 a.m. to 6 p.m. the draw need open only on the hour and half-hour; however, the draw need not open at 8 a.m., 12 noon, and 5 p.m. Monday through Friday except Federal holidays. From 7 a.m. to 6 p.m. on Saturdays, Sundays and Federal holidays the draw need only open on the hour and half-hour.

(e)-(g) [Reserved]

(h) George Musson/Coronado Beach (SR 44) bridge, mile 845 at New Smyrna Beach. The George Musson/Coronado Beach (SR 44) bridge, mile 845, shall open on signal, except that from 7 a.m. to 7 p.m., the draw shall open on the hour and half-hour, seven days a week.

(i) [Reserved]

(j) NASA Railroad bridge, mile 876.6 at Kennedy Space Center.

(1) The draw is not constantly tended.

(2) The draw is normally in the fully open position displaying flashing green lights to indicate that vessels may pass.

(3) When a train approaches the bridge, it stops and the operator initiates a command to lower the bridge. The lights go to flashing red and the draw lowers and locks, providing scanning equipment reveals nothing under the draw. The draw remains down until a manual raise command is initiated, or will raise automatically 5 minutes after the intermediate track circuit is no longer occupied by a rail car.

(4) After the train has cleared, the draw opens and the lights return to flashing green.

(k) [Reserved]