

§ 1918.54

be locked at the winch or the operating controls.

§ 1918.54 Rigging gear.

(a) *Guy and preventer placement.* Each guy or preventer shall be placed to prevent it from making contact with any other guy, preventer, or stay.

(b) *Guys.* When alternate positions for securing guys are provided, the guys shall be so placed as to produce a minimum stress and not permit the boom to jackknife.

(c) *Boom placement.* The head of the midship boom shall be spotted no farther outboard of the coaming than is necessary for control of the load.

(d) *Preventers.* (1) Preventers shall be properly secured to suitable fittings other than those to which the guys are secured, and shall be as nearly parallel to the guys as the fittings will permit.

(2) Unless the cleat is also a chock and the hauling part is led through the chock opening, the leads of preventers to cleats shall be such that the direction of the line pull of the preventer is as parallel as possible to the plane of the surface on which the cleat is mounted.

(3) Guys and associated preventers shall be adjusted to share the load as equally as possible where cargo operations are being conducted by burtoning. Exception: Where guys are designed and intended for trimming purposes only, and the preventer is intended to do the function of the guy, the guy may be left slack.

(e) *Cargo falls.* Cargo falls under load shall not be permitted to chafe on any standing or other running rigging. Exception: Rigging shall not be construed to mean hatch coamings or other similar structural parts of the vessel.

(f) *Bull wire.* (1) Where a bull wire is taken to a winch head for lowering or topping a boom, the bull wire shall be secured to the winch head by shackle or other equally strong method. Securing by fiber rope fastening does not meet this requirement.

(2) When, in lowering or topping a boom, it is not possible to secure the bull wire to the winch head, or when the topping lift itself is taken to the winch head, at least five turns of wire shall be used.

29 CFR Ch. XVII (7-1-10 Edition)

(g) *Trimming and deckloads.* When deck loads extend above the rail and there is less than 12 inches (30.48 cm) horizontal clearance between the edge of the deck load and the inside of the bulwark or rail, a pendant or other alternate device shall be provided to allow trimming of the gear and to prevent employees from going over the side.

[62 FR 40202, July 25, 1997, as amended at 65 FR 40945, June 30, 2000]

§ 1918.55 Cranes (See also § 1918.11).

The following requirements shall apply to the use of cranes forming part of a vessel's permanent equipment.

(a) *Defects.* Cranes with a visible or known defect that affects safe operation shall not be used. Defects shall be reported immediately to the officer in charge of the vessel.

(b) *Operator's station.* (1) Cranes with missing, broken, cracked, scratched, or dirty glass (or equivalent) that impairs operator visibility shall not be used.

(2) Clothing, tools and equipment shall be stored so as not to interfere with access, operation or the operator's view.

(c) *Cargo operations.* (1) Accessible areas within the swing radius of the body of a revolving crane or within the travel of a shipboard gantry crane shall be physically guarded or other equally effective means shall be taken during operations to prevent an employee from being caught between the body of the crane and any fixed structure, or between parts of the crane. Verbal warnings to employees to avoid the dangerous area do not meet this requirement.

(2) Limit switch bypass systems shall be secured during all cargo operations. Such bypass systems shall not be used except in an emergency or during non-cargo handling operations such as stowing cranes or derricks or performing repairs. Any time a bypass system is used, it shall be done only under the direction of an officer of the vessel.

(3) Under all operating conditions, at least three full turns of rope shall remain on ungrooved drums, and two full turns on grooved drums.

(4) Crane brakes shall be monitored during use. If crane brakes are unable

to hold the load, the crane shall not be used.

(5) Cranes shall not be used if control levers operate with excessive friction or excessive play.

(6) When cranes are equipped with power down capability, there shall be no free fall of the gear when a load is attached.

(7) When two or more cranes hoist a load in unison, a designated person shall direct the operation and instruct personnel in positioning, rigging of the gear and movements to be made.

(d) *Unattended cranes.* When cranes are left unattended between work periods, § 1918.66(b) (4)(i) through (v) shall apply.

Subpart G—Cargo Handling Gear and Equipment Other Than Ship's Gear

§ 1918.61 General (See also appendix IV of this part).

(a) *Employer provided gear inspection.* All gear and equipment provided by the employer shall be inspected by the employer or designated person before each use and, when appropriate, at intervals during its use, to ensure that it is safe. Any gear that is found upon such inspection to be unsafe shall not be used until it is made safe.

(b) *Safe working load.* (1) The safe working load of gear as specified in §§ 1918.61 through 1918.66 shall not be exceeded.

(2) All cargo handling gear provided by the employer with a safe working load greater than five short tons (10,000 lbs. or 4.54 metric tons) shall have its safe working load plainly marked on it.

(c) *Gear weight markings.* The weight shall be plainly marked on any article of stevedoring gear hoisted by ship's gear and weighing more than 2,000 lbs. (.91 metric tons).

(d) *Certification.* The employer shall not use any material handling device listed in paragraphs (f) and (g) of this section until the device has been certificated, as evidenced by current and valid documents attesting to compliance with the requirements of paragraph (e) of this section.

(e) *Certification procedures.* Each certification required by this section shall be performed in accordance with part

1919 of this chapter, by a person then currently accredited by OSHA as provided in that part.

(f) *Special gear.* (1) Special stevedoring gear provided by the employer, the strength of which depends upon components other than commonly used stock items such as shackles, ropes, or chains, and that has a Safe Working Load (SWL) greater than five short tons (10,000 lbs or 4.54 metric tons) shall be inspected and tested as a unit before initial use (see Table A in paragraph (f)(2) of this section). In addition, any special stevedoring gear that suffers damage necessitating structural repair shall be inspected and retested after repair and before being returned to service.

(2) Special stevedoring gear provided by the employer that has a SWL of five short tons (10,000 lbs. or 4.54 metric tons) or less shall be inspected and tested as a unit before initial use according to paragraphs (d) and (e) of this section or by a designated person (see Table A in this paragraph (f)(2)).

TABLE A

Safe working load	Proof load
Up to 20 short tons (18.1 metric tons) ..	25 percent in excess.
From 20 through 50 short tons (18.1 to 45.4 metric tons).	5 short tons in excess
Over 50 short tons (45.4 metric tons) ...	10 percent in excess

(g) Every spreader that is not a part of ship's gear and is used for handling intermodal containers shall be inspected and tested before initial use to a proof load equal to 25 percent greater than its rated capacity. In addition, any spreader that suffers damage necessitating structural repair shall be inspected and retested after repair and before being returned to service.

(h) All cargo handling gear covered by this section with a SWL greater than five short tons (10,000 lbs. or 4.54 metric tons) shall be proof load tested according to Table A in paragraph (f) or paragraph (g), as applicable, of this section every four years and in accordance with paragraphs (d) and (e) of this section or by a designated person.