

**Environmental Protection Agency**

**§ 141.74**

removal and/or inactivation of viruses. For a system that makes this demonstration, the requirements of paragraph (b) of this section apply. Beginning January 1, 2002, systems serving at least 10,000 people must meet the requirements for other filtration technologies in §141.173(b). Beginning January 14, 2005, systems serving fewer than 10,000 people must meet the requirements for other filtration technologies in §141.550 through 141.553.

[54 FR 27527, June 29, 1989, as amended at 63 FR 69516, Dec. 16, 1998; 66 FR 3776, Jan. 16, 2001; 67 FR 1836, Jan. 14, 2002; 69 FR 38855, June 29, 2004]

**§ 141.74 Analytical and monitoring requirements.**

(a) *Analytical requirements.* Only the analytical method(s) specified in this paragraph, or otherwise approved by EPA, may be used to demonstrate compliance with §§141.71, 141.72 and 141.73. Measurements for pH, turbidity, temperature and residual disinfectant concentrations must be conducted by a person approved by the State. Measurement for total coliforms, fecal coliforms and HPC must be conducted by a laboratory certified by the State or EPA to do such analysis. Until laboratory certification criteria are developed for the analysis of fecal coliforms and HPC, any laboratory certified for total coliforms analysis by the State or EPA is deemed certified for fecal coliforms and HPC analysis. The following procedures shall be conducted in accordance with the publications listed in the following section. This incorporation by reference was approved by the Director of the Federal Register in accordance with 5 U.S.C. 552(a) and 1 CFR part 51. Copies of the methods published in *Standard Methods for the Examination of Water and Wastewater* may be obtained from the American Public Health Association et al., 1015 Fifteenth Street, NW., Washington, DC 20005; copies of the Minimal Medium ONPG-MUG Method as set forth in the article “National Field Evaluation of a Defined Substrate Method for the Simultaneous Enumeration of Total Coliforms and *Esherichia coli* from Drinking Water: Comparison with the Standard Multiple Tube Fermentation Method” (Edberg et al.), Applied and Environ-

mental Microbiology, Volume 54, pp. 1595-1601, June 1988 (as amended under Erratum, Applied and Environmental Microbiology, Volume 54, p. 3197, December, 1988), may be obtained from the American Water Works Association Research Foundation, 6666 West Quincy Avenue, Denver, Colorado, 80235; and copies of the Indigo Method as set forth in the article “Determination of Ozone in Water by the Indigo Method” (Bader and Hoigne), may be obtained from Ozone Science & Engineering, Pergamon Press Ltd., Fairview Park, Elmsford, New York 10523. Copies may be inspected at the U.S. Environmental Protection Agency, Room EB15, 401 M St., SW., Washington, DC 20460 or at the National Archives and Records Administration (NARA). For information on the availability of this material at NARA, call 202-741-6030, or go to: [http://www.archives.gov/federal\\_register/code\\_of\\_federal\\_regulations/ibr\\_locations.html](http://www.archives.gov/federal_register/code_of_federal_regulations/ibr_locations.html).

(1) Public water systems must conduct analysis of pH and temperature in accordance with one of the methods listed at §141.23(k)(1). Public water systems must conduct analysis of total coliforms, fecal coliforms, heterotrophic bacteria, and turbidity in accordance with one of the following analytical methods or one of the alternative methods listed in appendix A to subpart C of this part and by using analytical test procedures contained in *Technical Notes on Drinking Water Methods*, EPA-600/R-94-173, October 1994. This document is available from the National Service Center for Environmental Publications (NSCEP), P.O. Box 42419, Cincinnati, OH 45242-0419 or <http://www.epa.gov/nscep/>.

Organism	Methodology	Citation <sup>1</sup>
Total Coliform <sup>2</sup> .....	Total Coliform Fermentation Technique <sup>3,4,5</sup> .	9221 A, B, C
	Total Coliform Membrane Filter Technique <sup>6</sup> .	9222 A, B, C
Fecal Coliforms <sup>2</sup> ...	ONPG-MUG Test <sup>7</sup>	9223
	Fecal Coliform Procedure <sup>8</sup> .	9221 E
Heterotrophic bacteria <sup>2</sup> .	Fecal Coliform Filter Procedure.	9222 D
	Pour Plate Method	9215 B
Turbidity <sup>13</sup> .....	SimPlate <sup>11</sup> .	2130 B
	Nephelometric Method.	

§ 141.74

40 CFR Ch. I (7-1-10 Edition)

Organism	Methodology	Citation <sup>1</sup>
	Nephelometric Method.	180.1 <sup>9</sup>
	Great Lakes Instruments.	Method 2 <sup>10</sup>
	Hach FilterTrak ....	10133 <sup>12</sup>

The procedures shall be done in accordance with the documents listed below. The incorporation by reference of the following documents listed in footnotes 1, 6, 7 and 9-12 was approved by the Director of the Federal Register in accordance with 5 U.S.C. 552(a) and 1 CFR part 51. Copies of the documents may be obtained from the sources listed below. Information regarding obtaining these documents can be obtained from the Safe Drinking Water Hotline at 800-426-4791. Documents may be inspected at EPA's Drinking Water Docket, 1301 Constitution Avenue, NW., EPA West, Room B102, Washington DC 20460 (Telephone: 202-566-2426); or at the National Archives and Records Administration (NARA). For information on the availability of this material at NARA, call 202-741-6030, or go to: [http://www.archives.gov/federal-register/code\\_of\\_federal\\_regulations/ibr\\_locations.html](http://www.archives.gov/federal-register/code_of_federal_regulations/ibr_locations.html).

<sup>1</sup>Except where noted, all methods refer to *Standard Methods for the Examination of Water and Wastewater*, 18th edition (1992), 19th edition (1995), or 20th edition (1998), American Public Health Association, 1015 Fifteenth Street, NW., Washington, DC 20005. The cited methods published in any of these three editions may be used. In addition, the following online versions may also be used: 2130 B-01, 9215 B-00, 9221 A, B, C, E-99, 9222 A, B, C, D-97, and 9223 B-97. Standard Methods Online are available at <http://www.standardmethods.org>. The year in which each method was approved by the Standard Methods Committee is designated by the last two digits in the method number. The methods listed are the only Online versions that may be used.

<sup>2</sup>The time from sample collection to initiation of analysis may not exceed 8 hours. Systems must hold samples below 10 deg. C during transit.

<sup>3</sup>Lactose broth, as commercially available, may be used in lieu of lauryl tryptose broth, if the system conducts at least 25 parallel tests between this medium and lauryl tryptose broth using the water normally tested, and this comparison demonstrates that the false-positive rate and false-negative rate for total coliform, using lactose broth, is less than 10 percent.

<sup>4</sup>Media should cover inverted tubes at least one-half to two-thirds after the sample is added.

<sup>5</sup>No requirement exists to run the completed phase on 10 percent of all total coliform-positive confirmed tubes.

<sup>6</sup>MI agar also may be used. Preparation and use of MI agar is set forth in the article, "New medium for the simultaneous detection of total coliform and *Escherichia coli* in water" by Brenner, K.P., et. al., 1993, *Appl. Environ. Microbiol.* 59:3534-3544. Also available from the Office of Water Resource Center (RC-4100T), 1200 Pennsylvania Avenue, NW., Washington DC 20460, EPA/600/J-99/225. Verification of colonies is not required.

<sup>7</sup>The ONPG-MUG Test is also known as the Autoanalysis Colilert System.

<sup>8</sup>A-1 broth may be held up to 7 days in a tightly closed screw cap tube at 4 °C.

<sup>9</sup>"Methods for the Determination of Inorganic Substances in Environmental Samples", EPA/600/R-93/100, August 1993. Available at NTIS, PB94-121811.

<sup>10</sup>GLI Method 2, "Turbidity," November 2, 1992, Great Lakes Instruments, Inc., 8855 North 55th Street, Milwaukee, WI 53223.

<sup>11</sup>A description of the SimPlate method, "IDEXX SimPlate TM HPC Test Method for Heterotrophs in Water," November 2000, can be obtained from IDEXX Laboratories, Inc., 1 IDEXX Drive, Westbrook, ME 04092, telephone (800) 321-0207.

<sup>12</sup>A description of the Hach FilterTrak Method 10133, "Determination of Turbidity by Laser Nephelometry," January 2000, Revision 2.0, can be obtained from: Hach Co., P.O. Box 389, Loveland, CO 80539-0389, telephone: 800-227-4224.

<sup>13</sup>Styrene divinyl benzene beads (e.g., AMCO-AEPA-1 or equivalent) and stabilized formazin (e.g., Hach StabiCal™ or equivalent) are acceptable substitutes for formazin.

(2) Public water systems must measure residual disinfectant concentrations with one of the analytical methods in the following table or one of the alternative methods listed in appendix A to subpart C of this part. If approved by the State, residual disinfectant concentrations for free chlorine and combined chlorine also may be measured by using DPD colorimetric test kits. In addition States may approve the use of the ITS free chlorine test strip for the determination of free chlorine. Use of the test strips is described in Method D99-003, "Free Chlorine Species (HOCl<sup>-</sup> and OCl<sup>-</sup>) by Test Strip," Revision 3.0, November 21, 2003, available from Industrial Test Systems, Inc., 1875 Langston St., Rock Hill, SC 29730. Free and total chlorine residuals may be measured continuously by adapting a specified chlorine residual method for use with a continuous monitoring instrument provided the chemistry, accuracy, and precision remain the same. Instruments used for continuous monitoring must be calibrated with a grab sample measurement at least every five days, or with a protocol approved by the State.

Residual	Methodology	SM <sup>1</sup>	SM Online <sup>2</sup>	Other
Free Chlorine	Amperometric Titration	4500-CI D	4500-CI D-00	D1253-03 <sup>3</sup>
	DPD Ferrous Titrimetric	4500-CI F	4500-CI F-00	
	DPD Colorimetric	4500-CI G	4500-CI G-00	
	Syringaldazine (FACTS)	4500-CI H	4500-CI H-00	
Total Chlorine	Amperometric Titration	4500-CI D	4500-CI D-00	D1253-03 <sup>3</sup>
	Amperometric Titration (low level measurement)	4500-CI E	4500-CI E-00	
	DPD Ferrous Titrimetric	4500-CI F	4500-CI F-00	
	DPD Colorimetric	4500-CI G	4500-CI G-00	
Chlorine Dioxide	Iodometric Electrode	4500-CI I	4500-CI I-00	327.0, Revision 1.1 <sup>4</sup>
	Amperometric Titration	4500-CI O <sub>2</sub> C	4500-CI O <sub>2</sub> C-00	
	DPD Method	4500-CI O <sub>2</sub> D	4500-CI O <sub>2</sub> D-00	
	Amperometric Titration	4500-CI O <sub>2</sub> E	4500-CI O <sub>2</sub> E-00	
Ozone	Spectrophotometric	4500-O <sub>3</sub> B	4500-O <sub>3</sub> B-97	327.0, Revision 1.1 <sup>4</sup>
	Indigo Method	4500-O <sub>3</sub> B	4500-O <sub>3</sub> B-97	

<sup>1</sup> All the listed methods are contained in the 18th, 19th, and 20th editions of *Standard Methods for the Examination of Water and Wastewater*, 1992, 1995, and 1998; the cited methods published in any of these three editions may be used.

<sup>2</sup> Standard Methods Online are available at <http://www.standardmethods.org>. The year in which each method was approved by the Standard Methods Committee is designated by the last two digits in the method number. The methods listed are the only Online versions that may be used.

<sup>3</sup> *Annual Book of ASTM Standards*, Vol. 11.01, 2004; ASTM International; any year containing the cited version of the method may be used. Copies of this method may be obtained from ASTM International, 100 Barr Harbor Drive, P.O. Box C700 West Conshohocken, PA 19428-2959.

<sup>4</sup> EPA Method 327.0, Revision 1.1, "Determination of Chlorine Dioxide and Chlorite Ion in Drinking Water Using Lissamine Green B and Horseradish Peroxidase with Detection by Visible Spectrophotometry," USEPA, May 2005, EPA 815-R-05-008. Available online at <http://www.epa.gov/safewater/methods/sourcall.html>.

§ 141.74

40 CFR Ch. I (7-1-10 Edition)

(b) *Monitoring requirements for systems that do not provide filtration.* A public water system that uses a surface water source and does not provide filtration treatment must begin monitoring, as specified in this paragraph (b), beginning December 31, 1990, unless the State has determined that filtration is required in writing pursuant to §1412(b)(7)(C)(iii), in which case the State may specify alternative monitoring requirements, as appropriate, until filtration is in place. A public water system that uses a ground water source under the direct influence of surface water and does not provide filtration treatment must begin monitoring as specified in this paragraph (b) beginning December 31, 1990, or 6 months after the State determines that the ground water source is under the direct influence of surface water, whichever is later, unless the State has determined that filtration is required in writing pursuant to §1412(b)(7)(C)(iii), in which case the State may specify alternative monitoring requirements, as appropriate, until filtration is in place.

(1) Fecal coliform or total coliform density measurements as required by §141.71(a)(1) must be performed on representative source water samples immediately prior to the first or only point of disinfectant application. The system must sample for fecal or total coliforms at the following minimum frequency each week the system serves water to the public:

System size (persons served)	Samples/week <sup>1</sup>
≤500 .....	1
501 to 3,300 .....	2
3,301 to 10,000 .....	3
10,001 to 25,000 .....	4
>25,000 .....	5

<sup>1</sup> Must be taken on separate days.

Also, one fecal or total coliform density measurement must be made every day the system serves water to the public and the turbidity of the source water exceeds 1 NTU (these samples count towards the weekly coliform sampling requirement) unless the State determines that the system, for logistical reasons outside the system's

control, cannot have the sample analyzed within 30 hours of collection.

(2) Turbidity measurements as required by §141.71(a)(2) must be performed on representative grab samples of source water immediately prior to the first or only point of disinfectant application every four hours (or more frequently) that the system serves water to the public. A public water system may substitute continuous turbidity monitoring for grab sample monitoring if it validates the continuous measurement for accuracy on a regular basis using a protocol approved by the State.

(3) The total inactivation ratio for each day that the system is in operation must be determined based on the CT<sub>99,9</sub> values in tables 1.1-1.6, 2.1, and 3.1 of this section, as appropriate. The parameters necessary to determine the total inactivation ratio must be monitored as follows:

(i) The temperature of the disinfected water must be measured at least once per day at each residual disinfectant concentration sampling point.

(ii) If the system uses chlorine, the pH of the disinfected water must be measured at least once per day at each chlorine residual disinfectant concentration sampling point.

(iii) The disinfectant contact time(s) ("T") must be determined for each day during peak hourly flow.

(iv) The residual disinfectant concentration(s) ("C") of the water before or at the first customer must be measured each day during peak hourly flow.

(v) If a system uses a disinfectant other than chlorine, the system may demonstrate to the State, through the use of a State-approved protocol for on-site disinfection challenge studies or other information satisfactory to the State, that CT<sub>99,9</sub> values other than those specified in tables 2.1 and 3.1 in this section other operational parameters are adequate to demonstrate that the system is achieving the minimum inactivation rates required by §141.72(a)(1).

**Environmental Protection Agency**

**§ 141.74**

**TABLE 1.1—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 0.5 °C OR LOWER<sup>1</sup>**

Residual (mg/l)	pH						
	≤6.0	6.5	7.0	7.5	8.0	8.5	≤9.0
≤0.4 ...	137	163	195	237	277	329	390
0.6 .....	141	168	200	239	286	342	407
0.8 .....	145	172	205	246	295	354	422
1.0 .....	148	176	210	253	304	365	437
1.2 .....	152	180	215	259	313	376	451
1.4 .....	155	184	221	266	321	387	464
1.6 .....	157	189	226	273	329	397	477
1.8 .....	162	193	231	279	338	407	489
2.0 .....	165	197	236	286	346	417	500
2.2 .....	169	201	242	297	353	426	511
2.4 .....	172	205	247	298	361	435	522
2.6 .....	175	209	252	304	368	444	533
2.8 .....	178	213	257	310	375	452	543
3.0 .....	181	217	261	316	382	460	552

<sup>1</sup>These CT values achieve greater than a 99.99 percent inactivation of viruses. CT values between the indicated pH values may be determined by linear interpolation. CT values between the indicated temperatures of different tables may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature and at the higher pH.

**TABLE 1.2—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 5.0 °C<sup>1</sup>**

Free residual (mg/l)	pH						
	≤6.0	6.5	7.0	7.5	8.0	8.5	≤9.0
≤0.4 ...	97	117	139	166	198	236	279
0.6 ..	100	120	143	171	204	244	291
0.8 ..	103	122	146	175	210	252	301
1.0 ..	105	125	149	179	216	260	312
1.2 ..	107	127	152	183	221	267	320
1.4 ..	109	130	155	187	227	274	329
1.6 ..	111	132	158	192	232	281	337
1.8 ..	114	135	162	196	238	287	345
2.0 ..	116	138	165	200	243	294	353
2.2 ..	118	140	169	204	248	300	361
2.4 ..	120	143	172	209	253	306	368
2.6 ..	122	146	175	213	258	312	375
2.8 ..	124	148	178	217	263	318	382
3.0 ..	126	151	182	221	268	324	389

<sup>1</sup>These CT values achieve greater than a 99.99 percent inactivation of viruses. CT values between the indicated pH values may be determined by linear interpolation. CT values between the indicated temperatures of different tables may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature, and at the higher pH.

**TABLE 1.3—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 10.0 °C<sup>1</sup>**

Free residual (mg/l)	pH						
	≤6.0	6.5	7.0	7.5	8.0	8.5	≤9.0
≤0.4 ...	73	88	104	125	149	177	209
0.6 ..	75	90	107	128	153	183	218
0.8 ..	78	92	110	131	158	189	226
1.0 ..	79	94	112	134	162	195	234

**TABLE 1.3—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 10.0 °C<sup>1</sup>—Continued**

Free residual (mg/l)	pH						
	≤6.0	6.5	7.0	7.5	8.0	8.5	≤9.0
1.2 ..	80	95	114	137	166	200	240
1.4 ..	82	98	116	140	170	206	247
1.6 ..	83	99	119	144	174	211	253
1.8 ..	86	101	122	147	179	215	259
2.0 ..	87	104	124	150	182	221	265
2.2 ..	89	105	127	153	186	225	271
2.4 ..	90	107	129	157	190	230	276
2.6 ..	92	110	131	160	194	234	281
2.8 ..	93	111	134	163	197	239	287
3.0 ..	95	113	137	166	201	243	292

<sup>1</sup>These CT values achieve greater than a 99.99 percent inactivation of viruses. CT values between the indicated pH values may be determined by linear interpolation. CT values between the indicated temperatures of different tables may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature, and at the higher pH.

**TABLE 1.4—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 15.0 °C<sup>1</sup>**

Free residual (mg/l)	pH						
	≤6.0	6.5	7.0	7.5	8.0	8.5	≤9.0
≤0.4 ...	49	59	70	83	99	118	140
0.6 ..	50	60	72	86	102	122	146
0.8 ..	52	61	73	88	105	126	151
1.0 ..	53	63	75	90	108	130	156
1.2 ..	54	64	76	92	111	134	160
1.4 ..	55	65	78	94	114	137	165
1.6 ..	56	66	79	96	116	141	169
1.8 ..	57	68	81	98	119	144	173
2.0 ..	58	69	83	100	122	147	177
2.2 ..	59	70	85	102	124	150	181
2.4 ..	60	72	86	105	127	153	184
2.6 ..	61	73	88	107	129	156	188
2.8 ..	62	74	89	109	132	159	191
3.0 ..	63	76	91	111	134	162	195

<sup>1</sup>These CT values achieve greater than a 99.99 percent inactivation of viruses. CT values between the indicated pH values may be determined by linear interpolation. CT values between the indicated temperatures of different tables may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature, and at the higher pH.

**TABLE 1.5—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 20 °C<sup>1</sup>**

Free residual (mg/l)	pH						
	≤6.0	6.5	7.0	7.5	8.0	8.5	≤9.0
≤0.4 ...	36	44	52	62	74	89	105
0.6 .....	38	45	54	64	77	92	109
0.8 .....	39	46	55	66	79	95	113
1.0 .....	39	47	56	67	81	98	117
1.2 .....	40	48	57	69	83	100	120
1.4 .....	41	49	58	70	85	103	123
1.6 .....	42	50	59	72	87	105	126

§ 141.74

40 CFR Ch. I (7-1-10 Edition)

TABLE 1.5—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 20 °C<sup>1</sup>—Continued

Free residual (mg/l)	pH						
	≤ 6.0	6.5	7.0	7.5	8.0	8.5	≤ 9.0
1.8 .....	43	51	61	74	89	108	129
2.0 .....	44	52	62	75	91	110	132
2.2 .....	44	53	63	77	93	113	135
2.4 .....	45	54	65	78	95	115	138
2.6 .....	46	55	66	80	97	117	141
2.8 .....	47	56	67	81	99	119	143
3.0 .....	47	57	68	83	101	122	146

<sup>1</sup> These CT values achieve greater than a 99.99 percent inactivation of viruses. CT values between the indicated pH values may be determined by linear interpolation. CT values between the indicated temperatures of different tables may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature, and at the higher pH.

TABLE 1.6—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY FREE CHLORINE AT 25 °C<sup>1</sup> AND HIGHER

Free residual (mg/l)	pH						
	≤ 6.0	6.5	7.0	7.5	8.0	8.5	≤ 9.0
≤ 0.4 ..	24	29	35	42	50	59	70
0.6 .....	25	30	36	43	51	61	73
0.8 .....	26	31	37	44	53	63	75
1.0 .....	26	31	37	45	54	65	78
1.2 .....	27	32	38	46	55	67	80
1.4 .....	27	33	39	47	57	69	82
1.6 .....	28	33	40	48	58	70	84
1.8 .....	29	34	41	49	60	72	86
2.0 .....	29	35	41	50	61	74	88
2.2 .....	30	35	42	51	62	75	90
2.4 .....	30	36	43	52	63	77	92
2.6 .....	31	37	44	53	65	78	94
2.8 .....	31	37	45	54	66	80	96
3.0 .....	32	38	46	55	67	81	97

<sup>1</sup> These CT values achieve greater than a 99.99 percent inactivation of viruses. CT values between the indicated pH values may be determined by linear interpolation. CT values between the indicated temperatures of different tables may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature, and at the higher pH.

TABLE 2.1—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY CHLORINE DIOXIDE AND OZONE<sup>1</sup>

	Temperature					
	< 1 °C	5 °C	10 °C	15 °C	20 °C	≥ 25 °C
Chlorine dioxide .....	63	26	23	19	15	11
Ozone .....	2.9	1.9	1.4	0.95	0.72	0.48

<sup>1</sup> These CT values achieve greater than 99.99 percent inactivation of viruses. CT values between the indicated temperatures may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature for determining CT<sub>99.9</sub> values between indicated temperatures.

TABLE 3.1—CT VALUES (CT<sub>99.9</sub>) FOR 99.9 PERCENT INACTIVATION OF GIARDIA LAMBLIA CYSTS BY CHLORAMINES<sup>1</sup>

Temperature					
< 1 °C	5 °C	10 °C	15 °C	20 °C	25 °C
3,800	2,200	1,850	1,500	1,100	750

<sup>1</sup> These values are for pH values of 6 to 9. These CT values may be assumed to achieve greater than 99.99 percent inactivation of viruses only if chlorine is added and mixed in the water prior to the addition of ammonia. If this condition is not met, the system must demonstrate, based on on-site studies or other information, as approved by the State, that the system is achieving at least 99.99 percent inactivation of viruses. CT values between the indicated temperatures may be determined by linear interpolation. If no interpolation is used, use the CT<sub>99.9</sub> value at the lower temperature for determining CT<sub>99.9</sub> values between indicated temperatures.

(4) The total inactivation ratio must be calculated as follows:

(i) If the system uses only one point of disinfectant application, the system may determine the total inactivation

ratio based on either of the following two methods:

(A) One inactivation ratio (CT<sub>calc</sub>/CT<sub>99.9</sub>) is determined before or at the first customer during peak hourly flow and if the CT<sub>calc</sub>/CT<sub>99.9</sub> ≥ 1.0, the 99.9 percent *Giardia lamblia* inactivation requirement has been achieved; or

(B) Successive CT<sub>calc</sub>/CT<sub>99.9</sub> values, representing sequential inactivation ratios, are determined between the point of disinfectant application and a point before or at the first customer during peak hourly flow. Under this alternative, the following method must be used to calculate the total inactivation ratio:

- (1) Determine  $\frac{CT_{calc}}{CT_{99,9}}$  for each sequence.
- (2) Add the  $\frac{CT_{calc}}{CT_{99,9}}$  values together  $\left(\sum \frac{CT_{calc}}{CT_{99,9}}\right)$
- (3) If  $\sum \left(\frac{CT_{calc}}{CT_{99,9}}\right) \geq 1.0$ , the 99.9 percent *Giardia*

*lamblia* inactivation requirement has been achieved.

(ii) If the system uses more than one point of disinfectant application before or at the first customer, the system must determine the CT value of each disinfection sequence immediately prior to the next point of disinfectant application during peak hourly flow. The  $CT_{calc}/CT_{99,9}$  value of each sequence and

$$\sum \frac{CT_{calc}}{CT_{99,9}}$$

must be calculated using the method in paragraph (b)(4)(i)(B) of this section to determine if the system is in compliance with §141.72(a).

(iii) Although not required, the total percent inactivation for a system with one or more points of residual disinfectant concentration monitoring may be calculated by solving the following equation:

$$\text{Percent inactivation} = 100 - \frac{100}{10^z}$$

$$\text{where } z = 3 \times \sum \left(\frac{CT_{calc}}{CT_{99,9}}\right)$$

(5) The residual disinfectant concentration of the water entering the distribution system must be monitored continuously, and the lowest value must be recorded each day, except that if there is a failure in the continuous monitoring equipment, grab sampling every 4 hours may be conducted in lieu of continuous monitoring, but for no more than 5 working days following the failure of the equipment, and systems serving 3,300 or fewer persons may take grab samples in lieu of providing

continuous monitoring on an ongoing basis at the frequencies prescribed below:

System size by population	Samples/day <sup>1</sup>
<500 .....	1
501 to 1,000 .....	2
1,001 to 2,500 .....	3
2,501 to 3,300 .....	4

<sup>1</sup>The day's samples cannot be taken at the same time. The sampling intervals are subject to State review and approval.

If at any time the residual disinfectant concentration falls below 0.2 mg/l in a system using grab sampling in lieu of continuous monitoring, the system must take a grab sample every 4 hours until the residual concentration is equal to or greater than 0.2 mg/l.

(6)(i) The residual disinfectant concentration must be measured at least at the same points in the distribution system and at the same time as total coliforms are sampled, as specified in §141.21, except that the State may allow a public water system which uses both a surface water source or a ground water source under direct influence of surface water, and a ground water source, to take disinfectant residual samples at points other than the total coliform sampling points if the State determines that such points are more representative of treated (disinfected) water quality within the distribution system. Heterotrophic bacteria, measured as heterotrophic plate count (HPC) as specified in paragraph (a)(3) of this section, may be measured in lieu of residual disinfectant concentration.

(ii) If the State determines, based on site-specific considerations, that a system has no means for having a sample transported and analyzed for HPC by a certified laboratory under the requisite

§ 141.74

40 CFR Ch. I (7-1-10 Edition)

time and temperature conditions specified by paragraph (a)(1) of this section and that the system is providing adequate disinfection in the distribution system, the requirements of paragraph (b)(6)(i) of this section do not apply to that system.

(c) *Monitoring requirements for systems using filtration treatment.* A public water system that uses a surface water source or a ground water source under the influence of surface water and provides filtration treatment must monitor in accordance with this paragraph (c) beginning June 29, 1993, or when filtration is installed, whichever is later.

(1) Turbidity measurements as required by §141.73 must be performed on representative samples of the system's filtered water every four hours (or more frequently) that the system serves water to the public. A public water system may substitute continuous turbidity monitoring for grab sample monitoring if it validates the continuous measurement for accuracy on a regular basis using a protocol approved by the State. For any systems using slow sand filtration or filtration treatment other than conventional treatment, direct filtration, or diatomaceous earth filtration, the State may reduce the sampling frequency to once per day if it determines that less frequent monitoring is sufficient to indicate effective filtration performance. For systems serving 500 or fewer persons, the State may reduce the turbidity sampling frequency to once per day, regardless of the type of filtration treatment used, if the State determines that less frequent monitoring is sufficient to indicate effective filtration performance.

(2) The residual disinfectant concentration of the water entering the distribution system must be monitored continuously, and the lowest value must be recorded each day, except that if there is a failure in the continuous monitoring equipment, grab sampling every 4 hours may be conducted in lieu of continuous monitoring, but for no more than 5 working days following the failure of the equipment, and systems serving 3,300 or fewer persons may take grab samples in lieu of providing continuous monitoring on an ongoing

basis at the frequencies each day prescribed below:

System size by population	Samples/day <sup>1</sup>
±500 .....	1
501 to 1,000 .....	2
1,001 to 2,500 .....	3
2,501 to 3,300 .....	4

<sup>1</sup> The day's samples cannot be taken at the same time. The sampling intervals are subject to State review and approval.

If at any time the residual disinfectant concentration falls below 0.2 mg/l in a system using grab sampling in lieu of continuous monitoring, the system must take a grab sample every 4 hours until the residual disinfectant concentration is equal to or greater than 0.2 mg/l.

(3)(i) The residual disinfectant concentration must be measured at least at the same points in the distribution system and at the same time as total coliforms are sampled, as specified in §141.21, except that the State may allow a public water system which uses both a surface water source or a ground water source under direct influence of surface water, and a ground water source to take disinfectant residual samples at points other than the total coliform sampling points if the State determines that such points are more representative of treated (disinfected) water quality within the distribution system. Heterotrophic bacteria, measured as heterotrophic plate count (HPC) as specified in paragraph (a)(1) of this section, may be measured in lieu of residual disinfectant concentration.

(ii) If the State determines, based on site-specific considerations, that a system has no means for having a sample transported and analyzed for HPC by a certified laboratory under the requisite time and temperature conditions specified by paragraph (a)(1) of this section and that the system is providing adequate disinfection in the distribution system, the requirements of paragraph (c)(3)(i) of this section do not apply to that system.

[54 FR 27527, June 29, 1989, as amended at 59 FR 62470, Dec. 5, 1994; 60 FR 34086, June 29, 1995; 64 FR 67465, Dec. 1, 1999; 67 FR 65252, Oct. 23, 2002; 67 FR 65901, Oct. 29, 2002; 69 FR 38856, June 29, 2004; 72 FR 11247, Mar. 12, 2007; 74 FR 30958, June 29, 2009]