

**§ 761.358**

**40 CFR Ch. I (7-1-10 Edition)**

**§ 761.358 Determining the PCB concentration of samples of waste.**

Use either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part, for chemical extraction of PCBs from individual and composite samples of PCB bulk product waste. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

**§ 761.359 Reporting the PCB concentrations in samples.**

Report all sample concentrations as ppm by weight on a dry weight basis.

**Subpart S—Double Wash/Rinse Method for Decontaminating Non-Porous Surfaces**

SOURCE: 63 FR 35472, June 29, 1998, unless otherwise noted.

**§ 761.360 Background.**

The double wash/rinse procedure is used to quickly and effectively remove PCBs on surfaces. It is important to select and use the proper cleanup equipment, to conduct the procedure correctly so as not to redistribute PCBs, and to comply with disposal requirements for all cleanup materials.

**§ 761.363 Applicability.**

The double wash/rinse procedure includes two washing steps and two rinsing steps. The two washing and rinsing steps are slightly different depending on whether a contaminated surface was relatively clean before the spill (see § 761.372), or whether the surface was coated or covered with dust, dirt, grime, grease or another absorbent material (see § 761.375).

**§ 761.366 Cleanup equipment.**

(a) Use scrubbers and absorbent pads that are not dissolved by the solvents or cleaners used, and that do not shred, crumble, or leave visible fragments on the surface. Scrubbers and absorbent pads used to wash contaminated surfaces must not be reused. Scrubbers and absorbent pads for rinsing must not contain  $\geq 2$  ppm PCBs. Scrubbers

and absorbent pads used in the second rinse of contaminated surfaces may be reused to wash contaminated surfaces.

(b) Capture and contain all solvents and cleaners for reuse, decontamination, or disposal. Clean organic solvents contain  $< 2$  ppm PCBs. Clean water contains  $< 3$  ppb PCBs.

**§ 761.369 Pre-cleaning the surface.**

If visible PCB-containing liquid is present on the surface to be cleaned, thoroughly wipe or mop the entire surface with absorbent paper or cloth until no liquid is visible on the surface.

**§ 761.372 Specific requirements for relatively clean surfaces.**

For surfaces that do not appear dusty or grimy before a spill, such as glass, automobile surfaces, newly-poured concrete, and desk tops, use the double wash/rinse procedures in this section.

(a) *First wash.* Cover the entire surface with organic solvent in which PCBs are soluble to at least 5 percent by weight. Contain and collect any runoff solvent for disposal. Scrub rough surfaces with a scrub brush or disposable scrubbing pad and solvent such that each 900 cm<sup>2</sup> (1 square foot) of the surface is always very wet for 1 minute. Wipe smooth surfaces with a solvent-soaked, disposable absorbent pad such that each 900 cm<sup>2</sup> (1 square foot) is wiped for 1 minute. Any surface  $< 1$  square foot shall also be wiped for 1 minute. Wipe, mop, and/or sorb the solvent onto absorbent material until no visible traces of the solvent remain.

(b) *First rinse.* Wet the surface with clean rinse solvent such that the entire surface is very wet for 1 minute. Drain and contain the solvent from the surface. Wipe the residual solvent off the drained surface using a clean, disposable absorbent pad until no liquid is visible on the surface.

(c) *Second wash.* Repeat the procedures in paragraph (a) of this section. The rinse solvent from the first rinse (paragraph (b) of this section) may be used.

(d) *Second rinse.* Repeat the procedures in paragraph (b) of this section.