

§ 761.250

segment contains ≥ 50 ppm PCB but < 500 ppm PCB.

(d) *Selecting the sample position—circumference.* Based on the mark on the top of the pipe segment made prior to removing pipe from the ground or lifting the pipe from its location during former operations, sample the inside center of the bottom of the pipe being sampled. Make sure the sample is centered on the bottom of the pipe segment; that is, sample an equal area on both sides of the middle of the bottom of the pipe segment for the entire length of the sample.

[63 FR 35462, June 29, 1998, as amended at 64 FR 33762, June 24, 1999]

§ 761.250 Sample site selection for pipeline section abandonment.

This procedure is for the sample site selection for a pipeline section to be abandoned, in accordance with § 761.60(b)(5)(i)(B).

(a) *General.* (1) Select sample collection sites in the pipeline section(s) by following the directions in paragraph (b) of this section.

(2) Select the proper sampling position along the pipe by following the directions in § 761.247 (c) and (d).

(3) Assure, by visual inspection, the absence of free-flowing liquids in the pipe by affirming no liquids at all liquid collection points and all ends of the pipeline section to be abandoned.

(b) *Selection sample collection sites.* At a minimum, sample all ends of all pipeline sections to be abandoned in place.

(1) If the pipeline section to be abandoned is between the pressure side of one compressor station and the suction side of the next compressor station downstream of the former gas flow, at a minimum, sample all ends of the abandoned pipe.

(2) If the pipeline section to be abandoned is longer than the distance between the pressure side of one compressor station and the suction side of the next compressor station downstream of the former gas flow, divide the pipeline section, for purposes of sampling, into smaller pipeline sections no longer than the distance from the pressure side of one compressor station to the suction side of the next compressor station downstream of the former gas flow. Consider each of the

40 CFR Ch. I (7–1–11 Edition)

smaller sections to be a separate abandonment and sample each one, at a minimum, at all ends.

(3) Use the following procedure to locate representative sample collection sites in pipeline sections at points other than the suction and pressure side of compressor stations, or the ends of the pipeline section to be abandoned.

(i) First, assign a unique identifying sequential number to each kilometer or fraction of a kilometer length of pipe within the entire pipeline section.

(ii) Use a random number table or a random number generator to select each representative sample collection site from a complete list of the sequential identification numbers.

(iii) Samples may be collected by removing any covering soil, cutting the pipe to gain access to the sampling location, and collecting the surface sample with the pipe in place, rather than completely removing the pipeline sections to collect the surface sample.

[63 FR 35462, June 29, 1998, as amended at 64 FR 33762, June 24, 1999]

§ 761.253 Chemical analysis.

(a) Extract PCBs from the standard wipe sample collection medium and clean-up the extracted PCBs in accordance with either Method 3500B/3540C or Method 3500B/3550B from EPA's SW-846, Test Methods for Evaluating Solid Waste, or a method validated under subpart Q of this part. Use Method 8082 from SW-846, or a method validated under subpart Q of this part, to analyze these extracts for PCBs.

(b) Report all PCB sample concentrations in $\mu\text{g}/100\text{ cm}^2$ (16 square inches) of surface sampled. If sampling an area smaller than 100 cm^2 , report converted sample concentrations in accordance with § 761.243(b).

§ 761.257 Determining the regulatory status of sampled pipe.

(a) For purposes of removal for disposal of a pipe segment that has been sampled, the sample results for that segment determines its PCB surface concentration. Determine the PCB surface concentration of a segment which was not sampled as follows:

(1) If the unsampled pipe segment is between two pipe segments which have been sampled, assume that the