## § 125.381

used as an alternate airport, but in no event may the landing minimums be less than a 300-foot ceiling and 1 mile of visibility.

- (b) The 100 hours of pilot-in-command experience required by paragraph (a) may be reduced (not to exceed 50 percent) by substituting one landing in operations under this part in the type of airplane for 1 required hour of pilot-incommand experience if the pilot has at least 100 hours as pilot in command of another type airplane in operations under this part.
- (c) Category II minimums, when authorized in the certificate holder's operations specifications, do not apply until the pilot in command subject to paragraph (a) of this section meets the requirements of that paragraph in the type of airplane the pilot is operating.

[Doc. No. 19779, 45 FR 67235, Oct. 9, 1980, as amended by Amdt. 125–52, 72 FR 31683, June 7, 2007]

## § 125.381 Takeoff and landing weather minimums: IFR.

- (a) Regardless of any clearance from ATC, if the reported weather conditions are less than that specified in the certificate holder's operations specifications, no pilot may—
- (1) Take off an airplane under IFR; or
- (2) Except as provided in paragraphs (c) and (d) of this section, land an airplane under IFR.
- (b) Except as provided in paragraphs (c) and (d) of this section, no pilot may execute an instrument approach procedure if the latest reported visibility is less than the landing minimums specified in the certificate holder's operations specifications.
- (c) A pilot who initiates an instrument approach procedure based on a weather report that indicates that the specified visibility minimums exist and subsequently receives another weather report that indicates that conditions are below the minimum requirements, may continue the approach only if either the requirements of §91.176 of this chapter, or the following conditions are met—
- (1) The later weather report is received when the airplane is in one of the following approach phases:
- (i) The airplane is on a ILS approach and has passed the final approach fix;

- (ii) The airplane is on an ASR or PAR final approach and has been turned over to the final approach controller; or
- (iii) The airplane is on a nonprecision final approach and the airplane—
- (A) Has passed the appropriate facility or final approach fix; or
- (B) Where a final approach fix is not specified, has completed the procedure turn and is established inbound toward the airport on the final approach course within the distance prescribed in the procedure; and
- (2) The pilot in command finds, on reaching the authorized MDA, or DA/DH, that the actual weather conditions are at or above the minimums prescribed for the procedure being used.
- (d) A pilot may execute an instrument approach procedure, or continue the approach, at an airport when the visibility is reported to be less than the visibility minimums prescribed for that procedure if the pilot uses an operable EFVS in accordance with §91.176 of this chapter and the certificate holder's operations specifications for EFVS operations, or for a holder of a part 125 letter of deviation authority, a letter of authorization for the use of EFVS.

[Doc. No. 19779, 45 FR 67235, Oct. 9, 1980, as amended by Amdt. 125–2, 46 FR 24409, Apr. 30, 1981; Amdt. 125–45, 69 FR 1641, Jan. 9, 2004; Amdt. 125–52, 72 FR 31683, June 7, 2007; Docket FAA–2013–0485, Amdt. 125–66, 81 FR 90177, Dec. 13, 2016]

## § 125.383 Load manifest.

- (a) Each certificate holder is responsible for the preparation and accuracy of a load manifest in duplicate containing information concerning the loading of the airplane. The manifest must be prepared before each takeoff and must include—
  - (1) The number of passengers;
- (2) The total weight of the loaded airplane;
- (3) The maximum allowable takeoff and landing weights for that flight;
- (4) The center of gravity limits;
- (5) The center of gravity of the loaded airplane, except that the actual center of gravity need not be computed if the airplane is loaded according to a loading schedule or other approved method that ensures that the center of gravity of the loaded airplane is within